

**LAKWOOD INSTRUMENTS
MODEL 2430Pe**

**MICROPROCESSOR-BASED
ORP AND CONDUCTIVITY CONTROLLER**

INSTALLATION & OPERATION MANUAL

SERIAL #: _____



Lakewood Instruments

7838 North Faulkner Road, Milwaukee, Wisconsin 53224 USA



Phone (800) 228-0839 • Fax (414) 355-3508

<http://www.lakewoodinstruments.com>

Lakewood Instruments™ Model 2430Pe Controller

Quick Installation Sheet

1. Attach the four (4) supplied mounting feet to the back of the controller enclosure either vertically or horizontally. Install the controller on a flat, non-vibrating surface. Do not mount the controller to a steel object that has a large temperature change (side of cooling tower, etc). This can cause water to condense inside the enclosure.
2. Install water meters, chemical pumps, plumbing assemblies, ORP sensor, and the conductivity sensor.
3. Install the provided strain reliefs with nuts, if necessary, by removing the attached black plugs and inserting strain relief through hole. Wire the flow switch, ORP sensor, conductivity sensor, water meters and 4-20 mA output; if applicable. Ensure wiring connections are correct or damage may occur.
4. If doing a conduit installation, remove receptacles and wire pumps and bleed valve directly to the terminals. If using a motorized ball valve, wire as per wiring instructions. Refer to the instruction manual for more details.
5. Plug in chemical pumps and valves to controller (unless hardwired as per step #4).
6. Apply power to the model 2430Pe controller, press "**CLR**" twice, press "**7**" System setup, press "**2**" Initialization, press "**2**" Whole controller, press "**1**" Yes. After initialization, press the "**CLR**" key several times until you get to the main menu.
7. Press "**1**" Process, Press "**ENT**". This screen allows manual control of the relay outputs to test the chemical pumps and valves. Press "**CLR**" to return to the Process screen.
8. Set the process parameters for your sensors See instruction manual for more details.
9. Calibrate the ORP and conductivity. Take a sample with a handheld meter, press the "**PRO**" button, select ORP or Conductivity and type in the ORP or conductivity value, press "**ENT**". See instruction manual for more details.
10. Program the model 2430Pe relays for chemical feed schemes. See instruction manual for more details.



IMPORTANT NOTICE

WARNING: CHEMICAL FEED

All electromechanical devices are subject to failure from a variety of causes. These include mechanical stress, component degradation, electromagnetic fields, mishandling, improper setup, physical abuse, chemical abuse, improper installation, improper power feeds, and exposure.

While every precaution is taken to insure proper functioning, extra precautions should be taken to limit the ability of over-feeding by limiting chemical quantities available, secondary shut-downs, alarms, and redundancy or other available methods.

CAUTION: POWER SOURCE AND WIRING

Low voltage wiring and high voltage (110 plus) should not be run in the same conduit. Always run separately. Even shielded low voltage is not a guarantee of isolation.

Every precaution should be taken to insure proper grounding and elimination of shorting or Electromagnetic field (EMF) interference.

WARNING: ELECTRICAL SHOCK

To reduce the risk of electrical shock, this equipment has a grounding-type plug that has a third (grounding) pin. This plug will only fit into a grounding-type outlet. If the plug does not fit into the outlet, contact a qualified electrician to install the proper outlet. **DO NOT** change the plug in any way.

Lakewood Instruments

We thank you for your selection and purchase of a Lakewood Instruments product.

With proper care and maintenance, this device should give you many years of trouble-free service. Please take the time to read and understand this Installation and Operation Manual, paying special attention to the sections on **OPERATION** and **MAINTENANCE**.

If, in the future, any parts or repairs are required, we strongly recommend that only original replacement parts be used. Our Customer Service Department is happy to assist you with your parts or service requests.

 **Lakewood Instruments Customer Service and Technical Support Departments can be reached by calling (800) 228-0839 or faxing (414) 355-3508, Monday through Friday, 7:30 a.m. - 5:00 p.m. CST. Our e-mail address is csd@lakewoodinstruments.com**

 **Mail should be sent to:**

**Lakewood Instruments
7838 North Faulkner Road
Milwaukee, WI 53224 USA**

MODEL 2430Pe

Table of Contents

1.0 Introduction	8
2.0 Features, Benefits and Specifications	9
2.1 Features	10
2.2 Benefits	10
2.3 Specifications	11
2.4 Ordering Information.....	12
3.0 Unpacking, Mounting and Installation	13
3.1 Unpacking	13
3.2 Mounting the Enclosure.....	13
3.3 Sensor Installation.....	14
3.3.1 Conductivity Sensor Plumbing.....	14
3.3.2 Conductivity Sensor wiring.....	14
3.3.3 ORP Sensor Plumbing.....	15
3.3.4 ORP Sensor Wiring	15
3.4 Electrical Installation.....	16
3.4.1 Incoming power 115/230 VAC	16
3.4.2 Relay Outputs.....	16
3.4.3 Flow Switch Input Wiring	17
3.4.4 Water Meter Wiring.....	17
3.4.5 4-20 mA Output Wiring	17
3.4.6 Node Wiring.....	18
4.0 Functional Overview.....	19
4.1 Display.....	19
4.2 Keypad	19
4.3 Menu	19
4.4 Security Levels	20
5.0 Starting Up the Controller.....	21
6.0 Operation of Controller	22
6.1 Process Screen	22
6.2 Manual Operation of the Relays.....	23
6.3 Calibration of Conductivity and ORP	24
6.3.1 Calibration of Conductivity.....	24
6.3.2 Calibration Check of conductivity in Buffer Solutions	24
6.3.3 Conductivity vs. ppm	25
6.3.4 Calibration of ORP	26
6.3.5 Single-Point Calibration	26
6.3.6 Two-Point Calibration	27
6.3.7 Calibration Check of ORP in Buffer Solutions	27
6.4 Main Menu.....	28

6.5 Configuring the Relays	29
6.5.1 Configuring the Blowdown Relay	29
6.5.1.1 Disabled	29
6.5.1.2 By Tower Setpoint	30
6.5.1.2.1 Setpoint	30
6.5.1.2.2 Deadband	30
6.5.1.2.3 Blowdown Timeout	31
6.5.1.3 By Makeup Volume	31
6.5.1.4 Change My Name	32
6.5.1.5 Scheduled Lockout?	32
6.5.1.6 Blowdown By Cycle Setpoint	33
6.5.1.7 By Multi-Setpoint	34
6.5.2 Configuring Relays 2, 3, 4	35
6.5.2.1 Disabled	35
6.5.2.2 By Setpoint	35
6.5.2.2.1 Setpoint	36
6.5.2.2.2 Deadband	36
6.5.2.2.3 Overfeed Time	36
6.5.2.2.4 When to Activate	37
6.5.2.3 By Water Meter	37
6.5.2.4 By Percent of Blowdown	37
6.5.2.5 By Percent of Time	38
6.5.2.6 By Feed Schedule	39
6.5.2.7 As an Alarm Relay	39
6.5.2.8 Change My Name	40
6.5.2.9 Scheduled Lockout?	40
6.5.3 Setting up the Feed Schedule	41
6.5.4 Alarms	43
6.5.5 Water Meters	44
6.5.6 4-20 mA Outputs	45
6.5.6.1 Setup of the 4-20 mA Output	45
6.5.6.1.1 Set the 4-20 mA Range	46
6.5.6.1.2 Calibrate	46
6.5.6.1.3 Which Process?	46
6.5.6.1.4 Manual Control	47
6.5.6.1.5 Change My Name	47
6.5.7 The System Setup Menu	47
6.5.7.1 Process Parameters	47
6.5.7.1.1 Change My Name	48
6.5.7.1.2 Temperature Compensation	48
6.5.7.1.3 Damping	49
6.5.7.1.4 Conductivity Preamp Setup	49
6.5.7.1.5 Cell Constant	50
6.5.7.1.6 Percent per °C	50
6.5.7.2 Initialization	51
6.5.7.3 Digital Inputs	51
6.5.7.4 Firmware Versions	51
6.5.7.5 Change the Security Passwords	52
6.5.7.6 Diagnostics	52

6.5.7.7	Communications	52
6.5.7.7.1	Com Port Setup.....	53
6.5.7.7.2	Initialize Modem	53
6.5.7.7.3	Remote Password	54
6.5.7.8	Node Installation	54
6.5.8	Setting the Clock.....	54
6.5.9	Changing the Security Levels	55
7.0	Maintenance.....	56
7.1	Sensor Maintenance.....	56
7.1.1	Conductivity Sensor	56
7.1.2	ORP Sensor.....	56
7.2	Replacing the Fuse.....	57
8.0	Troubleshooting	58
8.1	Error Messages	58
9.0	Factory Service	61
10.0	Drawings	
10.1	Installation Layout, 540 and 543 Sensors	1109745-1a
10.2	Installation Layout 530 ORP Sensor	1240520-1a
10.3	Wiring Diagram, 543 Sensor Wiring	1268870-2a
10.4	Wiring Diagram, 540 Sensor Wiring	1268870-1a
10.5	Wiring Diagram, ORP Sensor Wiring	1168332-1b
10.6	Wiring diagram for water meter inputs	1109544-3f
10.7	Wiring Diagram	1268647-1a
10.8	Electrical Schematic.....	1268647-2a
10.9	Wiring Diagram RS2L Option	1109708-1d
10.10	Wiring Diagram RS2L Option	1109708-2c
10.11	Wiring Diagram 4-20 mA output, 35L	1109707-1b
10.12	Wiring Diagram NIN Option.....	1167855-1a

1.0 INTRODUCTION

The Model 2430Pe is a LONWORKS Technology, microprocessor based, menu driven, ORP and conductivity water treatment controller. The Model 2430Pe provides for ORP and conductivity tracking and control, flow monitoring and chemical injection. The Model 2430Pe is CSA and ANSI/UL approved.

The Model 2430Pe uses the latest in microprocessor capability, giving the user a high level of application flexibility. A large illuminated graphics screen, multiple inputs, and an intuitive menu characterize this new technology.

Security features allow full access to programming features or restrict access to viewing only. An operator password can help ensure that only authorized personnel will operate the system.


The Model 2430Pe is user-friendly with a graphical screen and 16-key numeric keypad. It accepts multiple inputs and is easily configured. This controller can easily be upgraded in the field. It's a combination of reliability, accuracy, security and simplicity.

LONWORKS Technology gives you a high level of flexibility with the capability of adding nodes, additional inputs and outputs, for monitoring and control. These nodes have functions such as extra relay outputs, drum level inputs, pH inputs, conductivity inputs, ORP inputs, 4-20 mA inputs and water meter inputs.

Nodes are added using the –NIN option, according to a mapped network. The mapped network shows the full node addition capability of the LonWorks based 2000 series controllers.

The mapped network for the model 2430Pe shows that any or all of the following nodes can be added; two relay nodes, two 4-20 mA input nodes, two digital input nodes, four remote sensor nodes (any combination of pH, conductivity, or ORP), and one makeup conductivity node.

The complete mapped network is shown below.



2.0 Features, Benefits, Specifications



LOCK SCREWS

The lock screws keep your circuit boards secure and provide easy access for wiring and setup. Simply turn the lock screw and pull open the front panel.

16-BUTTON KEYPAD

ENT = for Menu selection and/or acceptance of selected values.

CLR = to exit a Menu selection and/or skip input options.

DSP = to change languages.

PRO = to program a Menu selection.

ENCLOSURE

A sturdy NEMA 4X rated enclosure protects your controller. Make sure it is properly mounted (SEE: **INSTALLATION; Mounting**). The power cord and receptacles can be removed so that the controller can be hardwired through 1/2" conduit knockouts.

Figure 1: **Model 2430Pe**

2.1 FEATURES

- ORP input with ORP sensor diagnostics indicates fouled reference or open PT band.
- Conductivity input with fouling compensation and alarm.
- Flowswitch lockout input.
- Two (2) water meter inputs. Records both makeup (**MTR1**) and Blowdown (**MTR2**) water meter total gallons.
- Configure Blowdown water meter (**MTR2**) as second makeup meter.
- One relay configured for bleed off and three user configurable relays for conductivity or ORP control and chemical addition. These relays can be configured in multiple ways including scheduled feed for biocide addition
- Blowdown Relay options:
 - Bleed x gallons for every x gallons makeup
 - Bleed x minutes for every x gallons of makeup
 - Bleed by setpoint
 - Bleed by cycles of concentration with **NCON/NCKT** Option
 - Bleed by multi-setpoint selected with **NCON/NCKT** Option
- User-selectable relay options:
 - Feed by setpoint, direct or reverse
 - Water meter actuated feed. **MTR1**, **MTR2** or the sum of the two
 - Percent of blowdown time
 - Percent of Time feed
 - Feed Schedule timer
 - General alarm
- Three security levels: View only, operator, technician
- 4-20 mA output available as an option.
- Remote communications available as an option.
- 16-key numeric keypad and illuminated graphical display allow for quick and easy programming.
- The Model 2430Pe controller stores all setpoints, calibration values, and relay configurations in an EEPROM. An EEPROM does not require a battery to retain information, so if power is lost these values will be retained for years. The 2430Pe includes a battery backup device to retain information such as water meter totals, and clock and calendar information. Battery life is approximately 3 months if no power is applied to the controller.

2.2 BENEFITS

- Multiple control options in a single economical package.
- Very accurate control of chemical feed and cycles of concentration.
- Feeds chemical after blowdown.
- Very low maintenance.
- Tolerant to power surges and brownouts.
- Power cord, plug outlets and attached plumbing make installation easy. There is plenty of protected room inside the enclosure for electrician wiring.
- Very accurate monitoring of the evaporated water.
- Has expansion slots to add additional control, such as additional relay outputs, 4-20 mA outputs, remote sensor inputs, digital inputs, and 4-20 mA inputs.

2.3 Specifications

Conductivity range

Based on sensor used

540K.01	1-10 μ S
540K.1	10-100 μ S
543LL	10-500 μ S
543L	100-1,000 μ S
543M	500-100,000 μ S

Conductivity Accuracy

\pm 1.0% of scale

Conductivity Resolution

Based on sensor used
1 μ S minimum

ORP range

-1000 to + 1000 mV

ORP Accuracy

\pm 5.0 mV

ORP Resolution

1 mV

Accuracy & Repeatability

\pm 1.0% of scale

Deadband/Setpoint

User programmable

Auto/Manual outputs

Menu selectable

Keypad

16 - key push buttons

Display

Illuminated 128 x 64
pixel LCD

Water meter inputs (2)

Contact head, paddle wheel or turbine

Timer

Relay run time exceeded.

Output relays

1 Bleed off
3 selectable use

Relay ratings

3A each, 10A total

Power

120/240 VAC 50/60 Hz 6W

Ambiant temp

32° - 158°F (0 - 70°C)

Storage temp

32° - 158°F (0 - 70°C)

Languages

Selectable:
English, plus one of:
Spanish
German
French

Enclosure

NEMA 4X

2.4 Ordering Information

2430Pe LONWORKS Technology-based ORP, conductivity, and water meter actuated chemical feed controller. The 2430Pe has built-in options for feed on ORP, conductivity, blowdown or makeup. Totalizing of makeup and blowdown, and three security levels are standard features. The controller includes a power cord and receptacles. Sensors must be purchased separately.

CONTROLLER OPTIONS

-35L Two 4-20 mA outputs configurable for remote data acquisition of conductivity and ORP.
-RS2L Communications node with shareware software
-NIN Network interface node. Allows 2 **NRLY**, 1 **Makeup NCON**, 4 sensor nodes (**NpH or NCON**), 2 **N420I** and/or 2 **NDIG** to be added.

LANGUAGE OPTIONS (optional, choose one, English and Spanish Standard)

-EF English and French.
-EG English and German.

REMOTE NODE OPTIONS (optional, MUST purchase -NIN Option)

NRLY Four additional relays with enclosure (2 per 2000 Series Controller).
NpH pH/ORP node for a pH or ORP sensor.
N420I 4-20 ma input node for up to 4 4-20 ma inputs.
NDIG Digital input node for up to 4 digital inputs.
NCON Conductivity node for makeup water or closed loop control (node only).
NCKT Conductivity node for makeup water or closed loop control with PVC sensor, tee and enclosure. Maximum water pressure is 140 psi @ 100 °F. Maximum temperature is 140°F.

NOTE: NOT FOR USE WITH MULTIPLE COOLING TOWERS.

SOFTWARE AND EXTERNAL MODEMS

LRWS *Windows*-based software for computer to communicate with 2000 Series Controllers
MD4X High-Baud modem in NEMA 4X enclosure ready to power
MD High-Baud modem for use with 2000 Series Controllers

3.0 Unpacking, Mounting and Installation

3.1 Unpacking

Inspect the shipping carton for obvious external damage. Note on the carrier's bill-of-lading the extent of the damage, if any, and **notify the carrier**. Save the shipping carton until your Model 2430Pe controller is started up.


☎ If shipping damage has occurred, call the Lakewood Instruments Customer Service Department at (800) 228-0839 and return the controller to the factory in the original carton.

3.2 Mounting the Enclosure

The Model 2430Pe is supplied with four mounting feet. The Model 2430Pe can be mounted to a panel or to a flat non-vibrating wall.

- Attach the four mounting feet to the back of the controller enclosure.
- Install on smooth surface to prevent stress on the mounting feet.
- Do not install on vibrating wall.
- If enclosure is installed in corrosive environments, consider purging.
- Dimensions indicated as inches (millimeters).
- The enclosure material is PVC.
- Use #10 mounting screws (4).
- Avoid drilling or punching additional holes in the controller enclosure. Damage incurred as a result of any alteration to the enclosure is not covered under the Lakewood Instruments product warranty.

The dimensions of the enclosure in inches are:



The model 2430Pe has a shipping weight of about 8 lbs.

NOTE: EXCESSIVE HEAT AND/OR DIRECT SUNLIGHT EXPOSURE WILL DARKEN THE LCD DISPLAY SCREEN, MAKING IT DIFFICULT TO READ, AND MAY SHORTEN THE LIFE OF OTHER ELECTRONIC COMPONENTS.

3.3 Sensor Installation

3.3.1 Conductivity Sensor Plumbing

The Conductivity sensor may be mounted in any position as long as the sensor tip is fully immersed in the active process water stream. Avoid connections in “dead leg” sections of pipe. An air pocket around the electrode tips will cause erroneous readings. The sensor electrodes should be in direct contact with the process flow (see DWG #04259 in the back of this manual).

Note: Remember to install isolation and bypass valves so that maintenance can be performed.

3.3.2 Conductivity Sensor Wiring

The model 2430Pe will accept the model 540K.1, the model 540K.01, the model 543M, the model 543L, and the model 543LL conductivity sensors. The conductivity sensor is wired directly to the I/O board inside the controller.

The 543 series sensors have 6 wires. They are as follows:

- Black wire Electrode
- Red wire Electrode
- White wire Electrode
- Green wire Electrode
- Black wire Temp compensation
- Black wire Temp compensation

The 540 series sensors have 4 wires. They are as follows:

- Black wire Outer Electrode
- Red wire Center Electrode
- White wire Temp compensation
- Green wire Temp compensation

For wiring instructions please refer to the drawings at the back of this manual.

The maximum allowed cable length between the sensor tip and the controller is twenty (20) feet. Cable length of conductivity sensors is measured from the electrode tips to the end of the wire. Lakewood Instruments guarantees operation up to 20 feet. If a cable extension is used, Lakewood Instruments will not guarantee operation of the sensor.

3.3.3 ORP Sensor Plumbing

The ORP sensor should be mounted vertically with the glass bulb facing down. It may be mounted at an angle as long as it is no more than 75° from the vertical position (see DWG #1240520-1a in the back of this manual). Due to the bubble position, however, the preferred mounting angle is no more than 45° from vertical.

The sensor must also be mounted in a location so that it is always wet. If is located in a pipe or tank with variable fluid levels, it is important that the sensor is installed where it can remain wet. Failure to do so will damage the sensor.

Remember to install isolation and bypass valves so that maintenance can be performed.

3.3.4 ORP Sensor Wiring

The model 2430Pe will accept the model 530 ORP sensor. The ORP sensor is wired directly to the I/O board inside the controller.

The 530 series sensors have 2 wires and a coaxial cable with a BNC fitting. They are as follows:

- BNC center ORP signal
- BNC Shield (not used)
- White wire Solution GND
- Green wire Reference

For wiring instructions please refer to the drawings at the back of this manual.

The maximum allowed cable length between the sensor tip and the controller is fifteen (15) feet. Cable length of ORP sensors is measured from the electrode tip to the end of the wire. Lakewood Instruments guarantees operation up to 15 feet. If a cable extension is used, Lakewood Instruments will not guarantee operation of the sensor.

Remember to install isolation and bypass valves so that maintenance can be performed.



If you have questions or need assistance, call Lakewood Instruments Technical Service Department at (800) 228-0839, Monday-Friday, 7:30 a.m. - 5:00 p.m. CST.

3.4 Electrical Installation

3.4.1 Incoming Power 115/230 VAC

The Model 2430Pe can be powered from either 115 VAC or 230 VAC at 50/60 Hz. The Model 2430Pe controller comes with a power cord and receptacles. The power cord and receptacles are rated for 115VAC. If the controller will be powered by 230 VAC, the power cord and receptacles will need to be removed and the incoming power and the relay outputs will need to be hard-wired.

The incoming power is connected to terminal block TA at the bottom right corner of the power supply board. There is a hot or line input (terminal 4), a neutral input (terminals 2 and 3) and an earth ground input (terminal 1). The hot is wired to the fuse holder located on the bottom of the enclosure. The neutrals are wired directly to terminals 2 and 3 of terminal block TA. Refer to the drawing in the back of this manual for wiring instructions.

3.4.2 Relay Outputs

The relay outputs are of the same voltage as the power input. Ensure that the devices that are to be connected to the relay outputs are of the same voltage rating or damage will occur.

The relay outputs are wired to the receptacles. The receptacle on the far left is relay #1 and the receptacle on the far right is relay #4. On the power supply board, relay #4 is on the far left and relay #1 is on the far right. If 115 VAC is used simply plug your devices into the molded receptacles. If 230 VAC is used, remove the receptacles and hard-wire your devices to the relay outputs.

Relay #1 and #2 have both a normally open and normally closed contact. This is designed for use with motorized valves. The normally open (NO) contact is connected to the open connection of the valve and the normally closed (NC) contact is connected to the close connection of the valve. The other two relays only have a normally open contact. Each relay output requires a neutral connection and an earth ground connection for proper operation.

Refer to the drawing in the back of this manual for wiring instructions.

WARNING! DO NOT PLUG IN CHEMICAL PUMPS THAT ARE LARGER THAN 1/6 HORSEPOWER. THE CONTROL RELAYS ARE INTENDED FOR ELECTRONIC OR SMALL MOTOR-DRIVEN CHEMICAL PUMPS. LARGER PUMPS REQUIRE THE -HR OPTION WITH 25-AMP-RATED INTERPOSING RELAYS. CONTACT LAKEWOOD INSTRUMENTS FOR SPECIAL INSTRUCTIONS.

3.4.3 Flow Switch Wiring

The model 2430Pe has a flow switch input. The purpose of the flow switch input is to disable the relay outputs on a loss of flow in the system. The flow switch input requires a digital contact. Any digital contact rated for 24 VDC and 500 mA may be used, such as a relay driven by the recirculation pump.

If a flow switch is not used then a jumper must be installed across the flow switch connections. Refer to the drawings in the back of this manual for wiring instructions.

3.4.4 Water Meters

The Model 2430Pe will accept two water meter inputs. These inputs can be configured for make-up, make-up Second Source, Bleed, or Chill Loop make-up. Refer to the water meter manufacturer's manual for plumbing information.

The 2430Pe series controllers will work directly with the following types of meters: dry contacting head meters, Seametrics open collector output meters, Signet 2535 and 2540 paddle wheel meters, and the Autotrol 1 inch and 2 inch meters. Contact Lakewood Instruments for other types of water meters. The water meters are wired to terminal block P1 which is the top terminal block on the I/O board.

Refer to the drawing in the back of this manual for wiring instructions.

3.4.5 4-20 mA Output Wiring

If the -35L option is ordered, the model 2430Pe has two channels of 4-20 mA output. This output can be isolated (externally powered) or non-isolated (internally powered). The 4-20 mA outputs are wired directly to the -35L option card.

Refer to the drawing in the back of this manual for wiring instructions.

3.4.6 Node Wiring

If the –NIN option is ordered with any external nodes (NpH, NCON, NRLY, NDIG, or N420I) they must be wired to the controller before installation and programming can take place. Nodes require +24 VDC for operation and twisted pair wire for data transmission. The NIN option card can provide the +24 VDC for up to two nodes using non-twisted pair wire. If using three or more nodes an external +24 VDC power supply run in parallel is recommended.

Recommended twisted pair for data specifications are:

Beldon 85102, single twisted pair, stranded 9/29, unshielded, plenum.

Beldon 8471, single twisted pair, stranded 9/29, unshielded, nonplenum.

JY (ST) Y 2 X 2 X .8, UL Level IV 22 AWG, twisted pair, typically solid and unshielded.

Four wire helical twist, solid, shielded.

If shielded cable is used, the shield should be connected to earth ground via a 470K ohm, .25 watt, metal film resistor to prevent static charge buildup.

Nodes are wired directly to the NIN card inside the controller enclosure.

Please refer to the diagram in the back of this manual for wiring instructions.

4.0 Functional Overview

4.1 Display

The model 2430Pe uses an illuminated 128x64-pixel LCD digital display for ease of viewing. It has multiple lines to display information such as the ORP reading, conductivity reading, alarms, relay status, relay configuration, clock, flow totals for both water meters, and menu selections.


4.2 Keypad

The model 2430Pe uses a 16-key numeric keypad for ease of programming. The keys have the following functions:

ENT	To accept a setting or to enter a screen.
CLR	To exit a screen or to access the main menu.
PRO	To calibrate the controller.
DSP	To change languages.
UP arrow	To move about in the menu.
DOWN arrow	To move about in a menu.
Number keys	To input a value or to select a menu item.

4.3 Menu

The model 2430Pe is programmed and calibrated by the use of a menu. The complete **Main Menu** has 8 available options that can be accessed in the **Technician Level**. However, a list of only six options can be viewed at one time. Use the **↑** and **↓** keys to scroll through the options. As an introduction, here is a graphic overview of the first level of each option in the **Main Menu** to see how it operates. Complete details of each option are provided later in this manual.



4.4 Security Levels

The model 2430Pe has a security levels to prevent tampering of the controller. The Model 2430Pe offers three (3) security levels: 1) **View Only**, 2) **Operator** and 3) **Technician**. When the controller is in the **View Only** or **Operator** security level, the menu is locked out. In **View Only**, access is limited to manual operation of the relays, and viewing all of the process screens. In the **Operator** mode the user can operate the relays manually, view the process screens, and calibrate the controller. He cannot change any other settings. In the **Technician** mode the operator has full access to all of the menus.

A password is required to change from a tight security level to a less restrictive security level. Each level has its own factory-preset password (2222 for Technician, 1111 for Operator). If the controller is in the **View Only** or **Operator** mode just press the appropriate password on the keypad to change to a less restrictive security mode.

The passwords can be changed to personalized passwords from the **Technician Level Menu**.

NOTE: IF YOU USE PERSONALIZED PASSWORDS, MAKE SURE THEY ARE RECORDED IN A SAFE AND SECURE PLACE.

5.0 Starting Up the Controller

Once the Installation is complete it is time to start up the controller.

Initiate sample flow to the sensors. Check for leakage.

Power up the controller by either turning on the circuit breaker or plugging the power cord into a 120 VAC receptacle.

It is best to initialize the whole controller to remove any settings that may be in the memory before programming the controller. Refer to section 6.5.7.2 of this manual to initialize the controller.

If applicable, install each node in software. Refer to section 6.5.7.8 and the applicable node manuals.

Set the process parameters for your sensors.

- Set up the temperature compensation per section 6.5.7.1.2

- Set up the conductivity preamp per section 6.5.7.1.5

- Set up the conductivity cell constant per section 6.5.7.1.6

Set the clock by following section 6.5.8.

Set the high and low conductivity and ORP alarms by following section 6.5.4.

Calibrate the ORP and conductivity by following section 6.3

Configure the relays for operation by following section 6.5.

Verify operation of the controller before leaving the area.

6.0 Operation of the Controller

6.1 Process Screen

The screen that is used the most in the 2430Pe controller is the Process Screen. Below are the process screen views. The process screen has three sections. The top section shows the ORP and conductivity readings. The alarm bar is the middle section and appears between the top and bottom sections. It is solid in appearance and flashes showing the current active alarms in sequence if there are multiple alarms. The bottom section has user selectable readings as shown below.

<p>1 - DATE SCREEN</p> <table border="1"> <tr> <td>ORP 300</td> <td>COND 1000</td> </tr> <tr> <td colspan="2">ALARM BAR</td> </tr> <tr> <td colspan="2">3 MAR '98</td> </tr> <tr> <td colspan="2">11:55:04</td> </tr> <tr> <td colspan="2">PRO=CALIB; ENT=RELAYS</td> </tr> </table>	ORP 300	COND 1000	ALARM BAR		3 MAR '98		11:55:04		PRO=CALIB; ENT=RELAYS		<ul style="list-style-type: none"> • There are many different screens available in the PROCESS screen. These screens allow you to view the unit's settings (incl. time setting, relay set-ups, total flow, etc.) without the danger of altering them. Access these screens by using the ↑ and ↓ keys to scroll through the available screens. • Press "ENT" to manually enable a relay for testing or troubleshooting purposes. • Press "PRO" to calibrate the conductivity. Press "CLR" to access the main menu. 																	
ORP 300	COND 1000																											
ALARM BAR																												
3 MAR '98																												
11:55:04																												
PRO=CALIB; ENT=RELAYS																												
<p>2 - ALL RELAY SCREEN</p> <table border="1"> <tr> <td>ORP 300</td> <td>COND 1000</td> </tr> <tr> <td colspan="2">NO FLOW</td> </tr> <tr> <td>BLOW RLY2</td> <td>RLY3 RLY4</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/> <input type="checkbox"/></td> </tr> <tr> <td colspan="2">PRO=CALIB; ENT=RELAYS</td> </tr> </table>	ORP 300	COND 1000	NO FLOW		BLOW RLY2	RLY3 RLY4	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	PRO=CALIB; ENT=RELAYS		<p>5 - RELAY 1,2,3,4 SETTINGS</p> <table border="1"> <tr> <td>ORP 300</td> <td>COND 1000</td> </tr> <tr> <td colspan="2">HIGH ORP</td> </tr> <tr> <td colspan="2">RLY4:</td> </tr> <tr> <td colspan="2">DISABLED</td> </tr> <tr> <td colspan="2"><input type="checkbox"/></td> </tr> <tr> <td colspan="2">PRO=CALIB; ENT=RELAYS</td> </tr> </table>	ORP 300	COND 1000	HIGH ORP		RLY4:		DISABLED		<input type="checkbox"/>		PRO=CALIB; ENT=RELAYS		<p>8 - ORP AND CONDUCTIVITY SCREEN</p> <table border="1"> <tr> <td>300 mV</td> </tr> <tr> <td>NO FLOW</td> </tr> <tr> <td>1000 μS</td> </tr> <tr> <td>PRO=CALIB; ENT=RELAYS</td> </tr> </table>	300 mV	NO FLOW	1000 μ S	PRO=CALIB; ENT=RELAYS
ORP 300	COND 1000																											
NO FLOW																												
BLOW RLY2	RLY3 RLY4																											
<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>																											
PRO=CALIB; ENT=RELAYS																												
ORP 300	COND 1000																											
HIGH ORP																												
RLY4:																												
DISABLED																												
<input type="checkbox"/>																												
PRO=CALIB; ENT=RELAYS																												
300 mV																												
NO FLOW																												
1000 μ S																												
PRO=CALIB; ENT=RELAYS																												
<p>3 - BLOW SETPOINT SCREEN</p> <table border="1"> <tr> <td>ORP 300</td> <td>COND 1000</td> </tr> <tr> <td colspan="2">OPENED TC</td> </tr> <tr> <td colspan="2">BLOW: COND SETPOINT=</td> </tr> <tr> <td colspan="2">1000 μS</td> </tr> <tr> <td colspan="2">PRO=CALIB; ENT=RELAYS</td> </tr> </table>	ORP 300	COND 1000	OPENED TC		BLOW: COND SETPOINT=		1000 μ S		PRO=CALIB; ENT=RELAYS		<p>6 - MTR1 TOTAL FLOW</p> <table border="1"> <tr> <td>ORP 300</td> <td>COND 1000</td> </tr> <tr> <td colspan="2">MTR1 TOTAL FLOW=</td> </tr> <tr> <td colspan="2">0</td> </tr> <tr> <td colspan="2">PRO=CALIB; ENT=RELAYS</td> </tr> </table>	ORP 300	COND 1000	MTR1 TOTAL FLOW=		0		PRO=CALIB; ENT=RELAYS		<p>If nodes are installed there will be additional screens for the additional inputs or outputs. Please see your specific node manual for more information.</p>								
ORP 300	COND 1000																											
OPENED TC																												
BLOW: COND SETPOINT=																												
1000 μ S																												
PRO=CALIB; ENT=RELAYS																												
ORP 300	COND 1000																											
MTR1 TOTAL FLOW=																												
0																												
PRO=CALIB; ENT=RELAYS																												
<p>4 - RELAY 2 SETTINGS</p> <table border="1"> <tr> <td>ORP 300</td> <td>COND 1000</td> </tr> <tr> <td colspan="2">RLY1 TIMEOUT</td> </tr> <tr> <td colspan="2">RLY2: BY MTR2 METER</td> </tr> <tr> <td colspan="2">FEED AFTER GALS/LTRS=</td> </tr> <tr> <td colspan="2">0 FOR 00:00 MM:SS</td> </tr> <tr> <td colspan="2">PRO=CALIB; ENT=RELAYS</td> </tr> </table>	ORP 300	COND 1000	RLY1 TIMEOUT		RLY2: BY MTR2 METER		FEED AFTER GALS/LTRS=		0 FOR 00:00 MM:SS		PRO=CALIB; ENT=RELAYS		<p>6 - MTR1 TOTAL FLOW</p> <table border="1"> <tr> <td>ORP 300</td> <td>COND 1000</td> </tr> <tr> <td colspan="2">MTR2 TOTAL FLOW=</td> </tr> <tr> <td colspan="2">0</td> </tr> <tr> <td colspan="2">PRO=CALIB; ENT=RELAYS</td> </tr> </table>	ORP 300	COND 1000	MTR2 TOTAL FLOW=		0		PRO=CALIB; ENT=RELAYS								
ORP 300	COND 1000																											
RLY1 TIMEOUT																												
RLY2: BY MTR2 METER																												
FEED AFTER GALS/LTRS=																												
0 FOR 00:00 MM:SS																												
PRO=CALIB; ENT=RELAYS																												
ORP 300	COND 1000																											
MTR2 TOTAL FLOW=																												
0																												
PRO=CALIB; ENT=RELAYS																												

6.2 Manual Operation of the Relays

All four of the relays can be operated manually. To manually operate the relays:

Go to the **Process** screen. Press “**ENT**”. You will be taken to a screen that looks like:

AUTO-MANUAL (5 MINS.)	
(1) BLOW	<input checked="" type="checkbox"/>
(2) RLY2	<input type="checkbox"/>
(3) RLY3	<input type="checkbox"/>
(4) RLY4	<input type="checkbox"/>
Press 1-4; CLR=EXIT	

Press “1-4 “ to manually change the state of that particular relay. If the relay is already on, pressing that number will turn it off. A five-minute countdown timer will start. After five minutes has expired the relay will return to automatic control. A relay that is in manual control will stay in manual control until the five minutes expires even if this screen is exited. The five-minute timer helps to prevent damage to the system if a relay is left in manual. **WARNING: Manual control overrides everything including the flow switch input. Use care when operating relays manually with no flow in the system.**

6.3 Calibration of Conductivity and ORP

6.3.1 CALIBRATION of CONDUCTIVITY

The conductivity requires periodic calibration. Calibration is usually required after cleaning the sensor.

Calibration should always be performed with the sensor in the piping assembly with good flow past the sensor. It is necessary to have an accurate reading of the blowdown water to properly calibrate the controller. A hand-held conductivity meter that tests the sample works well for this purpose. If a meter that measures ppm is used, refer to the conductivity vs. ppm chart in section 6.3.3 and convert the ppm to an approximate conductivity value. Buffers can be used to check calibrations but should not be used for calibration purposes (see below).

The model 2430Pe controller uses a single point calibration. A two point calibration is not necessary if using a Lakewood Instruments conductivity sensor.

- Ensure that the controller is operating with good flow past the sensor.
- Take a sample of the water and measure with a hand-held conductivity tester.
- From the **PROCESS** screen, press “**PRO**” to enter the calibration screen. Use the keypad to input the conductivity reading from the hand-held. Press “**ENT**”.
- Take another hand-held sample to verify calibration.

6.3.2 CALIBRATION CHECK OF CONDUCTIVITY IN BUFFER SOLUTIONS

To check the calibration of the sensor in buffer solutions, the sensor is placed in a container of the buffer solution. Ensure that the sensor tips are centered in the container away from the edges and the bottom of the container. The conductivity values displayed can vary depending on the position of the conductivity sensor in the container of buffer solution.

Perform the calibration check as follows:

- Shut the isolation valves to the controller plumbing assembly.
- Place the Conductivity sensor in the buffer solutions.
- Verify calibrations in at least two buffer solutions.
- Re-install the sensor into the plumbing. Ensure locking ring is locked.
- Restore flow to plumbing assembly

6.3.3 Conductivity vs. ppm

The model 2430Pe measures the conductivity of the water. The ppm of the water may be measured instead of conductivity. If ppm is measured, use the following chart for an approximation of the conductivity level and calibrate to the conductivity level that is closest to the ppm level that is measured. Remember this is just an approximation because the ions that make up the conductivity may be different than the particles that make up the ppm reading.

Conductivity vs. PPM Table

$\mu\text{S/cm}$	ppm	$\mu\text{S/cm}$	ppm	$\mu\text{S/cm}$	ppm
2	1	120	68	900	560
4	2.1	140	80	950	600
6	3.2	160	91	1000	630
8	4.2	180	100	1575	970
10	5.2	200	115	1575	1300
12	6.4	220	127	2500	1700
14	7.4	240	139	3000	1575
16	8.5	260	150	3400	2400
18	9.6	280	164	4000	2750
20	11.0	300	176	4500	3150
25	13.5	350	210	5000	3500
30	16.0	400	240	5500	3900
35	19.0	450	270	6000	4300
40	22.0	500	300	6500	4700
45	24.5	550	335	7000	5000
50	27.5	600	370	7500	5400
60	33.0	650	400	8000	5800
70	39.0	700	435	8500	6200
80	45.0	750	470	9000	6600
90	51.0	800	500	9500	7000
100	56.0	850	530	10,000	7400

6.3.4 CALIBRATION OF ORP

The model 2430Pe controller reads ORP in millivolts. To control free bromine or free chlorine pH and temperature must be maintained. 1 ppm of free chlorine at 7.5 pH and 25°C is equal to approximately 550-750 mV. This varies with different water quality.

When calibrating ORP keep in mind that it can be affected by several factors:

- pH
- Water quality
- Temperature

A single point calibration is sufficient for most applications using the model 2430Pe controller. A two point calibration can be performed if necessary.

If the ORP has been calibrated incorrectly you may restore the default values by initializing ORP calibration.

6.3.5 SINGLE-POINT CALIBRATION

We recommend that the ORP calibrations only be performed with the ORP sensor mounted as it will be used in the system.

It is necessary to have an accurate reading of the process water to properly calibrate the controller. A hand-held ORP meter that tests the sample is best. Once you have obtained a reading, immediately enter the value into the controller. In the process screen, press **PRO**. Select **ZERO**. Use the number keys to enter the value, and then press **ENT**. When the number is accepted, you will see the **CALIBRATION COMPLETE** screen before the LCD display switches back to the original **PROCESS** screen. Then take a second sample with a hand-held ORP meter and confirm the reading on the display.

6.3.6 TWO-POINT CALIBRATION

The model 2430Pe controller is capable of performing a two point calibration using both the **ZERO** and **SPAN** calibrations. To perform a good two-point calibration, buffers are used with the **ZERO** calibration buffer at least 200 mV lower than the **SPAN** calibration buffer.

To calibrate the sensor in buffer solutions, the sensor and a solution ground wire must be in the container of the buffer solution. Perform the two-point calibration as follows:

- Initialize the calibration.
- Shut the isolation valves to the sensor plumbing assembly.
- Place the ORP sensor into the lower value buffer solution.
- Press "**PRO**", select "**ZERO**". Use the keypad to enter the calibration value. Press "**ENT**".
- Place the sensor into the higher value buffer solution.
- Press "**PRO**", select "**SPAN**". Use the keypad to enter the calibration value. Press "**ENT**".
- Re-install the sensor into the plumbing.
- Restore flow to plumbing assembly
- Perform a single point calibration if necessary.

6.3.7 CALIBRATION CHECK OF ORP IN BUFFER SOLUTIONS

To check the calibration of the sensor in buffer solutions, the sensor and a solution ground wire are necessary. Perform the calibration check as follows:

- Initialize the calibrations.
- Shut the isolation valves to the sensor plumbing assembly.
- Place the ORP sensor into the buffer solutions.
- Verify calibrations in at least two buffer solutions at least 200 mV apart.
- Re-install the sensor into the plumbing.
- Restore flow to plumbing assembly
- Perform a single point calibration if necessary.

6.4 Main Menu

The **MAIN MENU** of the 2430Pe looks like this:

```
          MAIN MENU
          =====
1 PROCESS
2 RELAYS
3 FEED SCHEDULE
4 ALARMS
5 WATER METERS
6 4-20 MA IN/OUT
7 SYSTEM SETUP
8 CLOCK
```

The **MAIN MENU** can be accessed from the **PROCESS** screen by pressing “**CLR**”. If “**CLR**” is pressed and the **MAIN MENU** does not appear, the controller is probably in the **VIEW ONLY** or **OPERATOR** security mode. If the controller is in the **VIEW ONLY** or **OPERATOR** security mode, enter the **TECHNICIAN** security password to be able to access the **MAIN MENU**.

To move about in the menu screen use the **↑** and **↓** keys to highlight the desired option and press “**ENT**” or simply press the number key for the desired option.

Use the “**ENT**” key to accept a setting or to enter a screen. Use the “**CLR**” key to reject a setting or to exit a screen. From anywhere in the menu, pressing “**CLR**” will take you one step closer to the **MAIN MENU**.

Certain menu items are only visible if certain conditions apply, such as: nodes are installed, or other parameters are configured. If a menu item does not appear in the menu it most likely means that the option is not installed or configured.

Each of the **MAIN MENU** options is discussed in detail later in this manual.

6.5 Configuring the Relays

To access the relay configuration screen from the **MAIN MENU**, press “2” or highlight **RELAYS** and press “**ENT**”. The following screen will appear.

WHICH RELAY? =====
1 BLOW
2 RLY2
3 RLY3
4 RLY4

Select the relay that you want to program.

6.5.1 Configuring the Blowdown Relay

Below is the **RELAY OPTIONS** screen. The asterisk (*) next to one of the options tells you how that relay is configured.

The blowdown relay can be configured to operate based on a setpoint or based on a water meter input. When the blowdown relay is selected for programming the following screen will appear.

BLOW =====
1 DISABLED
2 *BY TOWER SETPOINT
3 BY MAKEUP VOLUME
4 CHANGE MY NAME
5 SCHEDULED LOCKOUT?

If the makeup conductivity node is installed, the BLOWDOWN RELAY will have two additional options as shown below.

BLOW =====
1 DISABLED
2 BY TOWER SETPOINT
3 BY MAKEUP VOLUME
4 BY CYCLE SETPOINT
5 BY MULTI-SETPOINT
6 CHANGE MY NAME
7 SCHEDULED LOCKOUT?

6.5.1.1 Disabled

The blowdown relay can be disabled. When a relay is disabled, it will not energize automatically.

- From the **RELAY OPTIONS** screen press “1” **Disabled** to disable the relay.

6.5.1.2 By Tower Setpoint

To set up the blowdown relay to operate based on a setpoint, select **BY TOWER SETPOINT**. The following screen will appear.

SETPOINT= 1000 μS
DEADBAND= 10 μS

6.5.1.2.1 SETPOINT

In the **SETPOINT** screen you will set the **SETPOINT**, the **DEADBAND** and the **BLOWDOWN TIMEOUT** alarm.

The **SETPOINT** is the Conductivity value that you are trying to maintain. Check with your water treatment engineer to determine the Conductivity setpoint for your system needs.

Follow these instructions to establish the controller's setpoint:

- Use the keypad numbers to enter the proper Conductivity setpoint and press "**ENT**". When finished, you will automatically be moved down to the deadband.

NOTE: A high conductivity alarm will override this setpoint and force a blowdown to occur.

6.5.1.2.2 DEADBAND

After the setpoint is established, the controller's deadband must also be set. "**Deadband**" refers to the amount of conductivity above and below the setpoint—a range within which the controller will not react. Due to continuous fluctuations in the conductivity level, it is necessary to have this deadband range or stable readings will be difficult to maintain. The Deadband should be a small percentage of the setpoint. Half the deadband amount will be automatically put above the setpoint, and the other half below it.

For example, a conductivity setpoint of 1000 μ S with a deadband of 20 μ S would result in the relay turning on at 1010 μ S and turning off at 990 μ S.

- Use the keypad numbers to enter the proper deadband setpoint and press "**ENT**". When finished, you will automatically be switched to the **BLOWDOWN TIMEOUT** alarm screen.

6.5.1.2.3 BLOWDOWN TIMEOUT

The **BLOWDOWN TIMEOUT** alarm is designed to notify the operator of a problem in the blowdown system such as, a clogged strainer, or the blowdown valve failed to open. The **BLOWDOWN TIMEOUT** function will display a visual alarm on the display, but it will **NOT** turn off the relay. If a relay is configured as an alarm relay, the **BLOWDOWN TIMEOUT** alarm will energize the alarm relay. To disable this function set the **BLOWDOWN TIMEOUT** time to 0:00.

- Use the keypad numbers to enter the time in hours and minutes before this alarm will appear and press "ENT". Maximum setting is 17 hours and 59 minutes.

6.5.1.3 BY MAKEUP VOLUME

NOTE: For this configuration of the blowdown relay, MTR 1 is always assumed to be the makeup water meter and MTR 2 is assumed to be the blowdown water meter. Ensure that this is the case with your wiring or conductivity control will not function properly.

To program the blowdown to be based on volume, select "3" **BY MAKEUP VOLUME** in the **BLOWDOWN RELAY** screen. The following screen will appear.

BY MAKEUP VOLUME =====
1 FOR BLOWDOWN FLOW
2 FOR BLOWDOWN TIME

There are two methods available to blowdown based on volume, **FOR BLOWDOWN FLOW** and **FOR BLOWDOWN TIME**.

With **FOR BLOWDOWN FLOW**, the blowdown relay will be on until a specified amount of blowdown is met after a specified amount of make-up has been received.

With **FOR BLOWDOWN TIME**, the blowdown relay will be on for a specified amount of time after a specified amount of make-up has been received.

If **FOR BLOWDOWN FLOW** is selected:

- Use the keypad to enter the volume of makeup after which you want to blowdown then press "ENT"
- Input the volume of blowdown that you want to blow down then press "ENT".
- The next screen is the **BLOWDOWN TIMEOUT** screen. Enter the amount of blowdown time before the **EXCESS BLOWDOWN TIME ALARM** will occur then press "ENT". **This alarm will close the blowdown valve** and it will give an alarm indication on the display. The alarm time is set in hours and minutes. To disable this feature, enter "00:00".

If **FOR BLOWDOWN TIME** is selected:

- Use the keypad to enter the volume of makeup after which you want to blowdown then press "**ENT**".
- You will automatically be moved down to the amount of time to blow down in hours and minutes. Enter the amount of time to blowdown and press "**ENT**".

6.5.1.4 CHANGE MY NAME

The name of each individual relay can be changed to any 4-character name. This is useful to designate the chemical name for each relay. Use the arrow keys to change the character and the ENT key to move to the next character.

OLD NAME= RLY2
NEW NAME= INH
<UP><DOWN>ENT: ACCEPT

- From the **BLOWDOWN RELAY OPTIONS** screen press "**4**" **CHANGE MY NAME**.

6.5.1.5 SCHEDULED LOCKOUT?

This setting allows the user the choice of whether to lock out a relay during a scheduled feed sequence or not. If you do not want to lock out this relay during a scheduled feed sequence select **NO**.

LOCK OUT RELAY DURING SCHEDULED FEED?
=====
1 * YES
2 NO

- From the **RELAY OPTIONS** screen press "**5**" **SCHEDULED LOCKOUT?**.
- Press "**1**" **YES** to lock out the relay during a scheduled feed or press "**2**" **NO** to allow the relay to operate normally during a feed schedule.

Note: This setting is only available and visible when the relay is set to operate based on **SETPOINT, WATER METER, or PERCENT of TIME**.

6.5.1.6 BLOWDOWN BY CYCLE SETPOINT

This option is only available if a conductivity node (NCON) is installed as the MAKEUP COND input.

If the NIN is installed with a conductivity node installed as the MAKEUP COND input the BLOWDOWN relay can be configured to blow down based on a cycle setpoint instead of a tower setpoint. The difference between the two is that a tower setpoint is a fixed conductivity value and does not change with a change in the makeup water conductivity. A cycle setpoint is the number of cycles of concentration of the cooling tower water that is desired and will adjust the actual tower setpoint automatically to maintain the cycles of concentration desired based on the makeup water conductivity. For example: If the tower setpoint is set to 1000 μ S, the controller will always try to maintain a reading of 1000 μ S in the cooling tower, no matter the value of the makeup water conductivity. If a cycle setpoint of 3.0 is set, the controller will always try to maintain a conductivity value in the cooling tower that is 3 times the current makeup water conductivity.

To set up the blowdown relay to operate based on a cycle setpoint, select **BY CYCLE SETPOINT**. The following screen will appear.

SETPOINT= 0.0
DEADBAND= 0.00

The setpoint is the number of cycles of concentration you want to maintain. The deadband is the number of cycles to use as the deadband. Refer to section 6.5.1.2.1, and 6.5.1.2.2, and 6.5.1.2.3 for a discussion on setpoint, deadband, and blowdown timeout.

- Use the keypad to enter a cycles of concentration setpoint. Press “**ENT**”.
- Use the keypad to enter a deadband value. Press “**ENT**”.
- Use the keypad numbers to enter the time in hours and minutes before the blowdown timeout alarm will appear and press “**ENT**”. Maximum setting is 17 hours and 59 minutes.
- The next screen is the “**WHEN TO ACTIVATE**” screen. Select “**1**” **ABOVE SETPOINT** to turn on the blowdown relay when the conductivity rises above the cycles of concentration setpoint, or select “**2**” **BELOW SETPOINT** to turn on the blowdown relay when the conductivity falls below the cycles of concentration setpoint.

6.5.1.7 BY MULTI-SETPOINT

This option is only available if a conductivity node (NCON) is installed as the MAKEUP COND input.

If the NIN is installed with a conductivity node installed as the MAKEUP COND input the BLOWDOWN relay can be configured to blow down based on multiple setpoints instead of a single tower setpoint. There are three different setpoints that can be established based on the value of the makeup water conductivity.

The user programs three ranges of makeup water conductivity and a setpoint for each of the three ranges. The controller determines which of the three setpoints to use based on the conductivity of the makeup water conductivity.

When **BY MULTI-SETPOINT** is selected in the blowdown relay setup screen the **MULTI-SETPOINT** screen is displayed.

```

      MULTI-SETPOINT
=====
1 SETPOINTS/RANGES
2 DEADBAND
3 BLOWDOWN TIMEOUT

```

- Press “1” **SETPOINTS/RANGES**

```

      SETPOINTS / RANGES
=====
1 1000, 0000 - 0300
2 1500, 0300 - 0500
3 2000, 0500 - UP

```

- Establish a setpoint for three ranges of makeup water conductivity. The first range always starts at 0 μ S. The second range starts at the top of the first range. The third range is any conductivity above the second range.

Refer to section 6.5.1.2.1, and 6.5.1.2.2, and 6.5.1.2.3 for a discussion on setpoint, deadband, and blowdown timeout.

6.5.2 Configuring Relays 2,3,4

Below is the **RELAY OPTIONS** screen. The asterisk (*) next to one of the options tells you how that relay is configured. Relays 2, 3, and 4 can be programmed in each of the methods shown on the **RELAY OPTIONS** screen.

```
          RLY2
          =====
1*DISABLED
2 SETPOINT
3 WATER METER
4 PERCENT BLOWDOWN
5 PERCENT OF TIME
6 FEED SCHEDULE
7 ALARM RELAY
8 CHANGE MY NAME
9 SCHEDULED LOCKOUT?
```

6.5.2.1 Disabled

Relays 2, 3, and 4 can be disabled. When a relay is disabled, it will not energize automatically.

- From the **RELAY OPTIONS** screen press “1” **Disabled** to disable the relay.

6.5.2.2 By Setpoint

Relays 2, 3, and 4 can be configured to operate based on a ORP or conductivity setpoint.

To set up the relay to operate based on a setpoint, select **SETPOINT** in the RELAY OPTIONS screen. A screen asking **WHICH PROCESS?** will appear. Select ORP or conductivity. If conductivity is selected the following screen will appear.

```
          SETPOINT=
          1000 µs

          DEADBAND=
          20 µs
          PRO: +/-  ENT: ACCEPT
```

6.5.2.2.1 SETPOINT

In the **SETPOINT** screen you will set the **SETPOINT**, the **DEADBAND** and the **OVERFEED TIME** alarm.

The **SETPOINT** is the conductivity or ORP value that you are trying to maintain. Check with your water treatment engineer to determine the conductivity and ORP setpoints for your system needs.

Follow these instructions to establish the controller's setpoint:

- Use the keypad numbers to enter the proper ORP or conductivity setpoint and press "**ENT**". When finished, you will automatically be moved down to the deadband.

6.5.2.2.2 DEADBAND

After the setpoint is established, the relay's deadband must also be set. "**Deadband**" refers to the amount of conductivity or ORP above and below the setpoint—a range within which the controller will not react. Due to continuous fluctuations in the conductivity and ORP level, it is necessary to have this deadband range or stable readings will be difficult to obtain. The Deadband should be a small percentage of the setpoint. Half the deadband amount will be automatically put above the setpoint, and the other half below it.

For example, a Conductivity setpoint of 1000 μS with a deadband of 20 μS would result in the relay turning on at 1010 μS and turning off at 990 μS .

- Use the keypad numbers to enter the proper deadband setpoint and press "**ENT**". When finished, you will automatically be switched to the **OVERFEED TIME** alarm screen.

6.5.2.2.3 OVERFEED TIME

The **OVERFEED TIME** alarm is designed to notify the operator of a problem in the chemical feed system such as, a pump has lost its prime or there is no chemical in the drum. It will also protect the system from overfeeding chemical when the indicated conductivity or ORP does not display a change in actual conductivity or ORP. The **OVERFEED** timeout function will display a visual alarm on the display and **it will turn off the relay**. If a relay is configured as an alarm relay, the **OVERFEED TIME** alarm will energize the alarm relay. To disable this function set the **OVERFEED** time to 0:00.

- Use the keypad numbers to enter the time in hours and minutes before this alarm will appear and press "**ENT**". Maximum setting is 17 hours and 59 minutes.

6.5.2.2.4 WHEN TO ACTIVATE

After configuring the SETPOINT, the DEADBAND, and the OVERFEED alarm, the controller will automatically move to the **WHEN TO ACTIVATE** screen. To set up to feed chemical on a rising ORP or conductivity set the relay to activate *above* the setpoint. To set up to feed on a falling ORP or conductivity set the relay to activate *below* the setpoint.

```
WHEN TO ACTIVATE
=====
1 *ABOVE SETPOINT
2 *BELOW SETPOINT
```

- Select “**1**” **ABOVE SETPOINT** to turn on the relay when the ORP or conductivity rises above the ORP or conductivity setpoint, or select “**2**” **BELOW SETPOINT** to turn on the relay when the ORP or conductivity falls below the ORP or conductivity setpoint.

6.5.2.3 By Water Meter

Relays 2, 3, and 4 can be configured to operate for a specified amount of time based on a specified amount of flow through the water meter inputs. **MTR1**, **MTR2** or the sum of **BOTH** water meter inputs can activate the relay.

- From the **RELAY OPTIONS** screen press “**3**” **WATER METER**.
- Select either **MTR1** or **MTR2** or **BOTH** as the trigger for the relay.
- Use the keypad to enter the amount of flow before the relay is activated. Press “**ENT**”.
- Enter the amount of time that the relay will be activated. Press “**ENT**”.

6.5.2.4 By Percent of Blowdown Time

Relays 2, 3, and 4 can be activated by a percent of the time that the blowdown was on. The relay will activate after the blowdown shuts off. For example, if 50% is entered and the blowdown relay is on for 10 minutes, the relay will be energized for 5 minutes.

- From the **RELAY OPTIONS** screen, press “**4**” **PERCENT BLOWDOWN**.
- Use the keypad to enter a percent of blowdown time to activate this relay. Press “**ENT**”.

6.5.2.6 By Feed Schedule

The feed schedule is used to feed chemicals such as biocides on a time of day basis. Setting up the feed schedule is a two-part process. The first part is to configure the relay so that it will operate by feed schedule. The second part of the process is to configure the feed schedule. The feed schedule is covered in section 6.5.3.

- From the **RELAY OPTIONS** screen press "**6**" **FEED SCHEDULE**.

The controller will respond with the following screen.

```
SCHEDULED RELAY
SEE MAIN MENU
FOR FEED SCHEDULE
PRESS ANY KEY
```

The relay has been configured to operate based on a feed schedule but, the relay will not activate because the feed schedule has not been programmed yet.

6.5.2.7 As an Alarm Relay

Relays 2, 3, and 4 can be configured as alarm relays. The alarms that will cause the relay to activate are selectable from the controller alarms or from any node input alarms. The controller alarms include: **HIGH CONDUCTIVITY, LOW CONDUCTIVITY, FOULED CONDUCTIVITY SENSOR, SHORTED TC, OPENED TC, HIGH ORP, LOW ORP, HIGH REFERENCE IMPEDANCE, OPEN PT BAND, HIGH REFERENCE VOLTAGE, LOW REFERENCE VOLTAGE, MAX BD TIME EXCEEDED, FEED SEQUENCE ACTIVE, RELAY #2 TIME EXCEEDED, RELAY #3 TIME EXCEEDED, RELAY #4 TIME EXCEEDED**, and the **NO FLOW** alarm.

- From the **RELAY OPTIONS** screen press "**7**" **ALARM RELAY**. The controller will respond with the following screen.

```
WHICH ALARMS?
=====
1 CONTROLLER
2 RELAYS 5-8
3 RELAYS 9-12
4 MAKEUP COND
5 REMOTE SENSOR
6 REMOTE SENSOR
7 REMOTE SENSOR
8 REMOTE SENSOR
9 ANALOG INPUTS (4)
10 ANALOG INPUTS (4)
11 DIGITAL INPUTS (4)
12 DIGITAL INPUTS (4)
```

- Select the alarms from this menu that will activate the relay.

6.5.2.8 Change My Name

The name of each individual relay can be changed to any 4-character name. This is useful to designate the chemical name for each relay. Use the arrow keys to change the character and the ENT key to move to the next character.

<p>OLD NAME= RLY2</p> <p>NEW NAME= INH</p>
<UP><DOWN>ENT: ACCEPT

- From the **RELAY OPTIONS** screen press "8" **CHANGE MY NAME**.

6.5.2.9 Scheduled Lockout?

This setting allows the user the choice of whether to lock out a relay during a scheduled feed sequence or not. If you do not want to lock out this relay during a scheduled feed sequence select **NO**.

<p>LOCK OUT RELAY DURING SCHEDULED FEED?</p> <p>=====</p> <p>1 * YES</p> <p>2 NO</p>

- From the **RELAY OPTIONS** screen press "9" **SCHEDULED LOCKOUT?**.
- Press "1" **YES** to lock out the relay during a scheduled feed or press "2" **NO** to allow the relay to operate normally during a feed schedule.

Note: This setting is only available and visible when the relay is set to operate based on **SETPOINT, WATER METER, PERCENT OF BLOWDOWN,** or **PERCENT of TIME**.

6.5.3 Setting up the Feed Schedule

Refer to section 6.5.2.5 to configure a relay to feed based on the feed schedule before continuing with this section.

To get to the feed schedule menu:

- From the **MAIN MENU** press "3" **FEED SCHEDULE**. You will see the following screen:

```
FEED SCHEDULE
=====
1*BY WEEKDAY
2 BY CYCLE CALENDAR
3 LIST SCHEDULE
```

The feed schedule can be programmed to feed chemicals by either **WEEKDAY** or by a **CYCLE CALENDAR** basis.

BY WEEKDAY is used to feed chemicals by the weekday name, i.e. Monday, Tuesday, Wednesday etc. This is a seven-day schedule. At the end of the week, the schedule starts over again. To configure the feed schedule to feed by weekday:

- From the **FEED SCHEDULE** screen, press "1" **BY WEEKDAY**.

BY CYCLE CALENDAR is used to feed chemicals by a schedule other than one that is seven days long. **BY CYCLE CALENDAR** can be used to feed the same chemical every day or up to 28 days between feedings. The operator specifies the number of days in the cycle calendar. After the cycle calendar is completed, the schedule starts over again. This method of feeding is particularly useful when feeding two biocides on alternating weekly basis. To configure the feed schedule to feed by cycle calendar:

- From the **FEED SCHEDULE** screen, press "2" **BY CYCLE CALENDAR**.
- Use the keypad to enter the number of days in your cycle then press "ENT". Remember the maximum number of days allowed is 28.
- Use the keypad to enter which day today is in your cycle, e.g. today is day number 5 in my 14 day cycle, then press "ENT".

After selecting whether the feed schedule will be fed by **WEEKDAY** or by **CYCLE CALENDAR** it is time to actually program the schedule. To enter the actual feed schedule or to edit the feed schedule from the feed schedule screen above:

- Press "3" **LIST SCHEDULE**. This will take you to a list of all scheduled feeds as shown in the screen on the next page.

NOTE: The maximum number of scheduled feeds is 16 (sixteen) total.

FEED SCHEDULE			
=====			
1	01	03:00	RLY2
2	00	00:00	
3	00	00:00	
4	00	00:00	
5	00	00:00	
6	00	00:00	

- If there are no scheduled feeds, select the first schedule and press "ENT". If you are editing the schedule, select the schedule that you want to edit and press "ENT".

Below is an example screen for programming a chemical feed. **Before programming a chemical feed, you need to configure Relay 2, 3, or 4 to be a feed schedule relay.**

RELAY (ARROWS): NONE
CYCLE DAY : 0
START TIME : 00:00
COND SETPOINT : 0
BLOW DURATION : 00:00
FEED DURATION : 00:00
LOCKOUT TIME : 00:00
<UP><DOWN>ENT: ACCEPT

- To program the schedule use the keypad to enter the values in the above screen. Press "ENT" to move to the next item.

NOTE: ALL TIMES ARE IN HOURS AND MINUTES

RELAY is which relay you want to program (you must configure a relay to be a feed schedule relay first). Use the arrow keys to select the available relays. Only relays that have been configured as feed schedule relays will appear.

CYCLE DAY or DAY is the day you wish to actuate the feed schedule relay.

START TIME is the time you want to start the feed schedule sequence. This start time uses the 24 hour clock or military time. **06:00:00** is 6 a.m. **18:00:00** is 6 p.m.

COND SETPOINT is a pre-bleed setpoint. This would typically be lower than the normal conductivity setpoint. Because the bleed valve may be disabled during a scheduled feed, a pre-bleed will help prevent a build up of tower conductivity. 0 μ S will disable this feature.

BLOW DURATION if the COND SETPOINT is not met within this time, the blowdown will stop and the feed schedule relay will be actuated. **If conductivity is disabled, this is the amount of time the controller will blow down during the pre-bleed sequence.** Inputting 0:00 will disable this feature. Lakewood Instruments recommends that some time be entered if pre-bleed is used.

FEED DURATION is the amount of time the feed schedule relay will be on.

LOCKOUT TIME after the feed duration is completed, an additional lockout time for **RLY 1, 2, 3, and 4** relays can be programmed. The lockout time prevents the other relays from operating until this time expires. **Setting this time to 0:00 will disable this feature.**

6.5.4 Alarms

The Model 2430Pe is equipped with both high and low conductivity and ORP alarms. This menu option allows you to program the specific values for these alarms. When a conductivity or ORP alarm is received, it will appear as a flashing message in the middle of the display and any configured alarm relays will be activated. **The high conductivity alarm will override the blowdown relay and force a blowdown to occur.** Consult your water treatment specialist when determining the proper High and Low Alarm values for your system.

To set the alarm setpoints:



HIGH ALARM=
5000 µS

LOW ALARM=
100 µS

PRO:+/- ENT: ACCEPT

- From the **MAIN MENU** press "4" **ALARMS**. A screen asking **WHICH PROCESS?** will appear. Select ORP or conductivity.
- Use the keypad to enter a value for the high alarm. Press "**ENT**".
- Use the keypad to enter a value for the low alarm and press "**ENT**".
- Use the keypad to enter a value for the deadband and press "**ENT**". Refer to section 6.5.1.2.2 for a discussion on deadband.

6.5.5 Water Meters

The 2430Pe series controllers will work directly with the following types of meters: dry contacting head meters, Seametrics open collector output meters, Signet 2535 and 2540 paddle wheel meters, and the Autotrol 1 inch and 2 inch meters. Contact Lakewood Instruments for other types of water meters.

Both water meter inputs are programmed in the same manner.

To get to the water meter configuration screen:

- From the **main menu**, press "5" **WATER METERS**. This will take you to the **WHICH WATER METER SCREEN**.
- Press "1" for **MTR1** or press "2" for **MTR2**.
- This will take you to the **WATER METER TYPES** screen as shown.

```
WATER METER TYPES
=====
1 CONTACTING HEAD
2 PADDLE WHEEL
3 DATA INDUSTRIAL
4 SIGNET
5 AUTOTROL TURB 1 IN.
6 AUTOTROL TURB 2 IN.
7 CHANGE MY NAME
```

- Use the keypad to select the type of water meter that you are using.

The next screen is the **UNITS OF VOLUME** screen.

- The water meters can be configured for gallons or liters. Press "1" for **GALLONS** or press "2" for **LITERS**.

If **CONTACTING HEAD** was selected:

- You will be taken to the **GALLONS OR LITERS PER CONTACT** screen. Use the keypad to enter the number of gallons or liters per contact for your specific meter then press "ENT". You will then be asked if you want to reset the total count for that meter to zero. Press "1" for **YES** or press "2" for **NO**.

If **PADDLE WHEEL** was selected:

- You will be taken to the **PULSES PER GAL/LITER** screen. Use the keypad to enter the pulses per gal/liter for your particular water meter then press "ENT". You will then be asked if you want to reset the total count for that meter to zero. Press "1" for **YES** or press "2" for **NO**.

If **DATA INDUSTRIAL** was selected:

- You will be taken to the **SLOPE VALUE** screen. Use the keypad to enter the K factor and offset values for your particular water meter then press "**ENT**". You will then be asked if you want to reset the total count for that meter to zero. Press "**1**" for **YES** or press "**2**" for **NO**.

If **SIGNET** was selected:

- You will be taken to the **K-FACTOR** screen. Use the keypad to enter the K-factor for your particular water meter then press "**ENT**". You will then be asked if you want to reset the total count for that meter to zero. Press "**1**" for **YES** or press "**2**" for **NO**.

If **AUTOTROL TURB 1 IN.** was selected:

- The controller will confirm that the **AUTOTROL TURB 1 IN.** has been selected and you will be asked if you want to reset the total count for that meter to zero. Press "**1**" for **YES** or press "**2**" for **NO**.

If the **AUTOTROL TURB 2 IN.** is selected:

- The controller will confirm that the **AUTOTROL TURB 2 IN.** has been selected and you will be asked if you want to reset the total count for that meter to zero. Press "**1**" for **YES** or press "**2**" for **NO**.


6.5.6 4-20 mA OUTPUTS

If the -35L option is ordered the model 2430Pe has two channels of 4-20 mA output. The -35L is an option card that can be added in the field.

6.5.6.1 Set Up of the 4-20 mA Output


To set up the 4-20 mA output:

- From the **Main Menu**, press "**6**" **4-20 mA OUTPUTS**



- Press "**1**" For **channel A** 4-20 mA OUT SETUP. Press "**2**" For **channel B** 4-20 mA OUT SETUP

The **4-20 mA Out Setup** screen allows the user to set the 4-20 mA range, calibrate the 4-20 mA output, select which process the 4-20 mA channel will respond to, take manual control of the 4-20 mA output, and change the name of the output. Below is the **4-20 mA Setup** screen.



6.5.6.1.1 Set the 4-20 mA Range

The 4-20 mA output range must be set for the output to be useful.

- From the **4-20 mA Setup** screen, press "1" **Set the 4-20 mA RANGE**.
- Use the keypad to enter a conductivity or ORP value for the 4-mA point. Press "ENT".
- Use the keypad to enter a conductivity or ORP value for the 20-mA point. Press "ENT".

6.5.6.1.2 Calibrate

The 4-20 mA needs to be calibrated to the actual output to be accurate. A milliamp meter is necessary to calibrate the 4-20 mA output. Connect the milliamp meter in-line with one leg of the 4-20 mA output. Refer to the drawing in the back of this manual for wiring instructions.

- From the **4-20 mA Setup** screen, press "2" **CALIBRATE**.
- Use the keypad to enter the milliamp reading from the milliamp meter for the 4-mA point. Press "ENT".
- Use the keypad to enter the milliamp reading from the milliamp meter for the 20-mA point. Press "ENT".

6.5.6.1.3 Which Process?

The two channels of 4-20 mA output can be configured to ORP and conductivity, or if the model 2430Pe has any remote sensor nodes attached, the 4-20 mA channel can be configured to operate based on that input.

- From the **4-20 mA Setup** screen, press "3" **WHICH PROCESS?**
- Use the up and down arrow keys to select the process that will control that channel of 4-20 mA output. Press "ENT".

6.5.6.1.4 Manual Control

Manual control is used to temporarily change the 4-20 mA output.

- From the **4-20 mA Setup** screen, press "4" **MANUAL CONTROL**.
- Use the up and down arrow keys to raise or lower the 4-20 mA output. To exit this screen press "CLR".

6.5.6.1.5 Change My Name

The name of the 4-20 mA output can be changed by the operator.


- From the **4-20 mA Setup** screen, press "5" **CHANGE MY NAME**.
- Use the arrow keys to change the characters, use the ENT key to move the cursor to the next character.

6.5.7 The System Setup Menu

The system setup menu is used to set up the temperature compensation, damping, initialize the controller, digital inputs, check the firmware version, change the security passwords, check the diagnostics, set up the communications, change the process names, and node installation.

6.5.7.1 Process Parameters

There are sub-screens in the process parameter screen for each of the process inputs. For the model 2430Pe there are screens for each of ORP, conductivity, and any nodes that may be installed. The WHICH PROCESS? screen will appear on the screen once Process Parameters is selected.



- Use the number keys to select the desired process input.

For ORP, the process parameters screen is used to change the name of the ORP process and to set the damping.

For conductivity, the process parameters screen is used to change the name of the conductivity process, the preamp setup, temperature compensation, cell constant, damping, and percent per °C.

6.5.7.1.1 Change My Name

The name of the process can be changed from **ORP** or **COND** to a different 4-character name.

To change the name of the process:

- From the Main Menu press "7" **SYSTEM SETUP**.
- Press "1" **PROCESS PARAMETERS**. Select **ORP** or **Cond**
- Press "1" **CHANGE MY NAME**.
- Use the arrow keys to change the characters, use the ENT key to move the cursor to the next character.

6.5.7.1.2 Temperature Compensation

Note: This screen is only located in the conductivity section of the process parameters.

Most Lakewood Instruments conductivity sensors are temperature compensated with the exception of the conductivity boiler sensors. The default value for the model 2430Pe is **500 NTC**.

The model 2430Pe has a single temperature compensator input. The input will come from the conductivity sensor. Set up the temperature compensation for the temperature compensator value of the sensor that is wired to the temperature compensation input.

The model **530** series ORP sensor is not temperature compensated.

Refer to the following table for the temp compensators for Lakewood Instruments conductivity sensors.

TEMP COMPENSATION

540 K.1	540 K.01	543M	543L	543LL
500 NTC	500 NTC	4K NTC	4K NTC	1K PTC

To set up the temperature compensation:

- From the Main Menu press "7" **SYSTEM SETUP**.
- Press "1" **PROCESS PARAMETERS**. Select **Cond**.
- Select **TEMP COMPENSATION**
- Select the value of your temperature compensator. Press "**ENT**".

6.5.7.1.3 Damping

Note: There are Damping screens for both the ORP and conductivity inputs. Make sure that you are in the correct screen for the process that you want to set a damping value for.

The rate of change of the ORP and conductivity values can be slowed down using DAMPING. If the ORP or conductivity value is changing quickly you can slow it down by:

- From the **Main Menu** press "7" **SYSTEM SETUP**.
- Press "1" **PROCESS PARAMETERS**. Select **ORP** or **Cond**.
- Select **DAMPING**.
- Use the keypad to change the DAMPING value. Input a larger number to slow the rate of change down or a smaller number to speed it up. Press "ENT".

6.5.7.1.4 Conductivity Preamp Setup

The internal preamp must be set up for the conductivity sensor that is used. Refer to the following tables for the preamp setup for Lakewood Instruments conductivity sensors.

RANGES

Cond Range	540 K.1	540 K.01	543M	543L	543LL
1-10	Range 4	Range 3	-	Range 2	Range 2
10-100	Range 3	-	Range 3	Range 2	Range 2
100-500	-	-	Range 2	Range 2	Range 2
100-1000	-	-	Range 2	Range 2	-
1000-10000	-	-	Range 1	-	-
10000-100000	-	-	Range 0	-	-

PREAMPLIFIER SETTINGS FOR THE MODEL 2430Pe

	Range 0	Range 1	Range 2	Range 3	Range 4
Voltage Gain	100	10	10	10	1
Sample R	20	20	200	2K	2K
Drive. Freq.	500 Hz	500 Hz	500 Hz	500 Hz	30 Hz

To set up the preamp:

- From the Main Menu press "7" **SYSTEM SETUP**.
- Press "1" **PROCESS PARAMETERS** Select **Cond**.
- Press "2" **PREAMP SETUP**.
- Use the arrow keys to change the **VOLTAGE GAIN**, use the **ENT** key to move the cursor to the **SAMPLE R**.
- Use the arrow keys to change the **SAMPLE R**, use the **ENT** key to move the cursor to the **DRIVE FREQ**.

6.5.7.1.5 Cell Constant

The cell constant must be set up for the conductivity sensor that is used. Refer to the following table for the cell constants for Lakewood Instruments conductivity sensors.

CELL CONSTANTS

540 K.1	540 K.01	543M	543L	543LL
0.1	0.01	0.30	0.03	0.07

To set up the Temperature Compensation:

- From the Main Menu press "7" **SYSTEM SETUP.**
- Press "1" **PROCESS PARAMETERS.** Select **Cond.**
- Press "4" **CELL CONSTANT.**
- Use the keypad to enter the **CELL CONSTANT** as per the table above and press the **ENT** key.

6.5.7.1.6 Percent per °C

Conductivity values are temperature dependent. The degree to which temperature affects the conductivity value is based on the many different ions that may be present. This menu item allows the user to adjust the compensation value to more closely match the different ions that may be present in the process. The default value is 2 percent per °C (the approximate compensation value for NaCl).

The degree to which temperature affects conductivity can be calculated using the following formula:

$$G_t = G_{t_{cal}} \{1 + \alpha(T - T_{cal})\}$$

where: G_t = conductivity at any temperature T in °C, $G_{t_{cal}}$ = conductivity at calibration temperature T_{cal} in °C, α = temperature coefficient of solution at T_{cal} in °C.

To determine that α of other solutions, simply measure conductivity at a range of temperatures and graph the change in conductivity versus the change in temperature. Divide the slope of the graph by $G_{t_{cal}}$ to get α .


To set up the Percent per °C:

- From the Main Menu press "7" **SYSTEM SETUP.**
- Press "1" **PROCESS PARAMETERS.**
- Press "6" **PERCENT PER °C.**
- Use the keypad to enter the **PERCENT PER °C** value and press the **ENT** key.

6.5.7.2 Initialization

Initialization restores the factory default settings to the controller. The whole controller can be initialized or just the calibration. It is suggested that you initialize the whole controller before you program the controller. This will clear any random settings that may be in the controller. To do so, follow these instructions:

- From the **Main Menu**, press **"7" SYSTEM SETUP**.
- Press **"2" INITIALIZATION**.
- Press **"2" WHOLE CONTROLLER** and press **"ENT"**. A warning will appear on the screen (see below). Press **"1"** to proceed, **"2"** to cancel.



To initialize just the calibration:

- Press **"1" CALIBRATIONS** instead of **"2" WHOLE CONTROLLER** in the procedure above. Select **ORP** or **conductivity**. The same warning screen will appear.

6.5.7.3 Digital Inputs

If the model 2430Pe controller has a digital input node (NDIG) installed the inputs are configured from this screen. If a NDIG is not installed there is no access to this menu item. Configuration of the digital inputs are covered in the NDIG manual.

6.5.7.4 Firmware Versions

Sometimes it is necessary to verify the firmware version of the controller for troubleshooting purposes. To obtain the firmware versions:


- From the **Main Menu**, press **"7" SYSTEM SETUP**.
- Press **"4" FIRMWARE VERSION**.
- The firmware versions will be displayed. Use the arrow keys to see all firmware versions. To exit this screen, press **"CLR"**.

6.5.7.5 Change the Security Passwords

The security password can be changed from the factory default settings to any four-digit value of your choice.

To change the security passwords:

- From the **Main Menu**, press **"7" SYSTEM SETUP**.
- Press **"5" SECURITY**.



- Press **"1" OPERATOR** to change the operator password or Press **"2" TECHNICIAN** to change the technician password.
- Use the keypad to enter the old password. If the password has not been changed before, the old password for **OPERATOR** is **1111** and the password for **TECHNICIAN** is **2222**.
- Use the keypad to enter the new password.
- Use the keypad to enter the new password a second time for verification

If you lose your password, contact Lakewood Instruments for assistance.

6.5.7.6 Diagnostics


The diagnostics screen is used for troubleshooting purposes. Contact Lakewood Instruments for assistance.

6.5.7.7 Communications

The model 2430Pe has an option for remote communications, the –RS2L option. If this option is installed the communications option is configured from this screen. This screen is used to set up the com port, initialize the modem, and set the remote password.

To set up the communications option:

- From the **Main Menu**, press **"7" SYSTEM SETUP**.
- Press **"7" COMMUNICATIONS**.



6.5.7.7.1 Com Port Setup

Com port setup is used to set up the com port for use with a modem or direct connect.

- To set up the com port press “1” **COM PORT SETUP**

```
COM PORT PARAMETERS
=====
BAUD RATE:  19200
DATA BITS:  8
STOP BITS:  1
PARITY      :  NONE
<UP><DOWN> ENT: ACCEPT
```

- Use the arrow keys to change the baud rate. If using the direct connect method of communicating, ensure that the baud rate at the controller and the baud rate in the LRWS software match.
- The standard values for the **DATA BITS** is 8, **STOP BITS** is 1, and **PARITY** is NONE. Normally these will not need to be changed.

6.5.7.7.2 Initialize Modem

Before a modem can be used by the controller it must be initialized. The initialization screen gives four choices of modems.

To initialize the modem:

- From the Communications menu, press “2” **INITIALIZE MODEM**

```
INITIALIZE MODEM
=====
1 HAYES ACCURA
2 U.S. ROBOTICS
3 ZOOM
4 OTHER MODEM
```

- Select your modem from the list. If your modem is not listed and you select **OTHER MODEM** use the keypad to enter the initialization string for your modem.
- If the modem fails to initialize, check the 25-pin connector, the phone cable, the modem, and the –RS2L option card.

6.5.7.7.3 Remote Password

Remote communications to the Lakewood Instruments 2000 series controllers is protected with an 8-digit password. The remote password is required to make changes to the model 2430Pe controller using the communications option card.

The remote password screen in the communications menu is used to change the remote password. The remote password can only be changed at the controller.

To change the remote password:

- From the communications menu, press “3” **REMOTE PASSWORD**.
- Use the keypad to enter the old password. Enter the new password. Repeat the new password again for verification. **NOTE: The default password is 12345678.**
- Set the remote password in the LRWS program to match the new password for this controller.


6.5.7.8 Node Installation

The node installation menus is used to install new nodes and to de-install installed nodes. Please refer to your node manual for information on node installation.

6.5.8 Setting the Clock

The clock uses the 24 hour or military time. **06:00:00** is 6 a.m. **18:00:00** is 6 p.m. To set the clock:

- From the **Main Menu** press “8” **CLOCK**. The following screen will appear:



- Press “**PRO**” to change the clock settings.
- Use the up and down arrow keys to change the day of the week. Press “**ENT**”.
- Use the number keys to change the date. Press “**ENT**”.
- Use the arrow keys to change the month. Press “**ENT**”.
- Use the number keys to change the year. Press “**ENT**”.
- Use the number keys to change the hour. Press “**ENT**”.
- Use the number keys to change the minutes. Press “**ENT**”.
- Use the number keys to change the seconds. Press “**ENT**”.
- Press “**CLR**” to exit this screen.

You must press “**ENT**” all the way through this menu for the settings to take affect.

6.5.9 Changing the Security Levels

The security level can be change to prevent any unwanted tampering of the controller. To change the security level from **Technician** to **Operator** or **View-Only**:

- From the **Main Menu**, press “0”. (*Note that “0” does not appear on the menu screen.*)

CHANGE LEVEL TO OPERATOR ? WARNING:YOU SHOULD KNOW THE PASSWORD. 1 YES 2 NO

- Select **YES** to change the security level to a more restrictive level.

The controller menu now functions at the new security level.

To return to the **Technician** security level:

- Press the numeric password from the **Process** screen:

TECHNICIAN PRESS ANY KEY

Remember that following the first power-up the Technician password is 2222 and the Operator password is 1111. You may change the passwords in the SYSTEM SETUP menu.

7.0 Maintenance

Periodic maintenance is required to ensure trouble free operation of the model 2430Pe controller. The following sections cover the required maintenance.

7.1 Sensor Maintenance

Routine maintenance is necessary in order to maximize the efficiency and accuracy of your sensor.

7.1.1 Conductivity Sensor

Clean the electrode end of the Conductivity sensor at least once per month. Cleaning of the Conductivity sensor may need to be performed more frequently if it is in a high fouling environment.

- Remove power from the controller and shut off the sample flow.
- Remove the sensor from its plumbing.
- Clean the electrodes with a wire brush. A soft steel brush is preferable over a brass brush. Do not use cloth to clean the electrodes. Cloth has oils that will foul the sensor.
- If there is oil on the sensor glass, use isopropyl alcohol to clean the electrode.
- It is recommended that you use a 10% Muriatic or HCL acid to clean the sensor if necessary.
- Wash the sensor off with tap water.
- Install the sensor in its plumbing.
- Restore sample flow and check for leaks.
- Restore power to the controller.
- Perform a calibration of the Conductivity.

7.1.2 ORP Sensor

Clean the electrode end of the ORP sensor at least once per month. Cleaning of the ORP sensor may need to be performed more frequently if it is in a high fouling environment.

- Remove power from the controller and shut off the sample flow.
- Remove the sensor from its plumbing.
- Be careful not to touch the glass electrode. Do not use cloth to clean the electrode. Cloth has oils that will foul the sensor.
- If there is oil on the sensor glass, use isopropyl alcohol to clean the electrode.
- It is recommended that you use a 10% Muriatic or HCL acid to clean the sensor.
- Wash the sensor off with tap water.
- Install the sensor in its plumbing.
- Restore sample flow and check for leaks.
- Restore power to the controller.
- Allow the reading to stabilize for approximately 30 minutes.
- Perform a calibration of the ORP.

7.2 Replacing the Fuse

The Model 2430Pe contains a 10A, 250V fuse. The fuse holder is located on the bottom of the enclosure. It is accessible from the outside of the box. Replacement fuses must be a fast blow type. If the fuse is blown, the display will be blank and the four power supply lights inside the controller enclosure will be dark when the unit is connected to power. Refer to the troubleshooting section of this manual for more information about blank displays.

8.0 Troubleshooting

8.1 Error Messages

This section discusses some of the more common questions with the Model 2430Pe. These notes are not intended to be all-inclusive—only to cover the most common situations. If you have other questions or are need support, contact the Lakewood Instruments Technical Service Department toll free at (800) 228-0839.

PROBLEM	WHAT THIS MEANS	CORRECTIVE ACTION
{Alarm Flashing} “Conductivity: HIGH ALARM”.	Conductivity is too high with respect to the high alarm setpoint.	<ol style="list-style-type: none"> 1. Check the High Alarm Value. 2. Check relay setpoints and deadbands. 3. Check operation of bleed-off valve. Use the manual relay control to help. 4. Check blowdown valve is not stuck closed or the line is restricted.
{Alarm Flashing} “Conductivity: LOW ALARM”.	Conductivity is too low with respect to the low alarm setpoint.	<ol style="list-style-type: none"> 1. Check the Low Alarm Value. 2. Check relay setpoints and deadbands. 3. Check blowdown valve is not stuck open. 4. Check that the system is not overflowing.
Water meters not accumulating.	<p>There may be a problem with the wiring or the reed switch in the meter may be bad.</p> <p>For water meters other than the contacting head type, check the manufacturer’s user manual for that particular water meter.</p>	<ol style="list-style-type: none"> 1. Approximately 24 volts DC should be present at the input terminal when the water meter contact is closed. That should change to zero VDC when the contact opens. Check these voltages and for correct wiring. 2. Is the controller configured for your type of water meter?
{Alarm Flashing} “FEED SEQUENCE ACTIVE”.	This simply indicates that a feed schedule relay is active.	No action necessary.
Display is blank.	There may be a problem with the incoming power, the fuse or the circuit board. Open the front panel to troubleshoot.	<ol style="list-style-type: none"> 1. Check the fuse. Replace if blown. 2. Does the unit have power? Verify with volt meter. 3. If there is power to terminals LINE and NEUTRAL on TA, call Lakewood Instruments Technical Service for more information.

PROBLEM	WHAT THIS MEANS	CORRECTIVE ACTION
<p>{Alarm Flashing} “RLY: TIME EXCEEDED”.</p>	<p>This indicates that the controller has been trying to feed chemical for longer than the user-programmed time and is unable to reach the setpoint.</p>	<ol style="list-style-type: none"> 1. Check for proper operation of pump or valve. Use the manual relay control to help. 2. Check that the chemical drum is not empty. 3. Check for power to the chemical pump. 4. Verify the relay timeout time is properly set for your application (see RELAYS in MAIN menu). 5. To reset this alarm, momentarily turn off flow to the controller to get the no flow alarm.
<p>“NO FLOW” alarm.</p>	<p>Flow input switch is not closed.</p>	<ol style="list-style-type: none"> 1. The flow switch float may be stuck or no flow is present. 2. Flow switch may be bad. Replace reed switch in plumbing assembly. 3. If no flow switch is used, a jumper wire should be installed across the flow switch input. Removing the jumper disables all relay outputs.
<p>Bleed valve relay is closed above setpoint.</p>	<p>Controller may be in biocide schedule.</p>	<p>Check feed schedule.</p>
<p>Bleed valve relay is open below setpoint.</p>	<p>High conductivity alarm will force the bleed valve to open. Controller may be doing a pre-bleed before feeding biocide.</p>	<ol style="list-style-type: none"> 1. Check High conductivity alarm setpoint. Change setpoint if necessary. 2. Check feed schedule. Adjust as necessary.

PROBLEM	WHAT THIS MEANS	CORRECTIVE ACTION
“SENSOR READS ZERO”	You are trying to perform a span calibration of the conductivity and the conductivity sensor reads zero.	<ol style="list-style-type: none"> 1. Check wiring. 2. Ensure sensor is full immersed in water. 3. The model 2430Pe for cooling towers will not accept a span calibration below about 200 μS. Cycle conductivity higher and re-calibrate.
{ALARM FLASHING} “COND:Fouled SENSOR”	Conductivity sensor is not reading properly.	<ol style="list-style-type: none"> 1. Clean sensor. 2. Check wiring. Verify that all connectors are fully mated. 3. Replace conductivity sensor.
{Alarm Flashing} “ORP: HIGH ALARM”.	ORP is too high with respect to the high alarm setpoint.	<ol style="list-style-type: none"> 1. See {RLY: TIME EXCEEDED}. 2. Check the High Alarm Value. 3. Check relay setpoints and deadbands. 4. Check chemical drum levels. 5. Check proper operation of chemical pumps.
{Alarm Flashing} “ORP: LOW ALARM”.	ORP is too low with respect to the low alarm setpoint.	<ol style="list-style-type: none"> 1. See {RLY: TIME EXCEEDED}. 2. Check the Low Alarm Value. 3. Check relay setpoints and deadbands. 4. Check chemical drum levels.
Water meters not accumulating.	<p>There may be a problem with the wiring or the reed switch in the meter may be bad.</p> <p>For water meters other than the contacting head type, check the manufacturer’s user manual for that particular water meter.</p>	<ol style="list-style-type: none"> 1. Approximately 24 volts DC should be present at the input terminal when the water meter contact is closed. That should change to zero VDC when the contact opens. Check these voltages and for correct wiring. 2. Is the controller configured for your type of water meter?

9.0 Factory Service



Technical Support for Lakewood Instruments can be reached by calling (800) 228-0839 or faxing (414) 355-3508, Monday through Friday, 7:30 a.m. – 5.00 p.m. CST.

NOTE: IF YOU CALL FOR TROUBLESHOOTING HELP, PLEASE HAVE THE MODEL NUMBER, SERIAL NUMBER, AND ANY OPTIONS PERTAINING TO YOUR UNIT AVAILABLE FOR REFERENCE.



Mail and returns should be sent to:

**Lakewood Instruments
7838 North Faulkner Road
Milwaukee, WI 53224 USA**

When any merchandise is to be returned to the factory, please call and obtain a Return Goods Authorization (RGA) number and have the following information available:

- Customer's name, address, telephone and fax numbers (shipping and billing).
- A hard copy purchase order number for cases where repairs or parts are required that are not under warranty.
- A contact person's name and telephone number to call if the equipment is beyond repair or to discuss any other warranty matter.
- Equipment model and serial numbers.
- Reason for return, e.g., repair, warranty, incorrect part, etc.

We will then fax to your attention an RGA form that must accompany the returned item.

NOTE: THE RGA NUMBER MUST BE CLEARLY WRITTEN ON THE OUTSIDE OF THE PACKAGE(S) BEING RETURNED.

**ANY ITEMS SENT BACK TO THE FACTORY
WITHOUT AN RGA NUMBER WILL BE REFUSED
AND RETURNED TO SENDER**

Parts List and Service Guide

When calling Lakewood Instruments, please have your controller's complete model number and serial number available, together with the firmware version so that the Technician can better assist you.

Refer to the Ordering Information section of this manual for part numbered replacement parts.

Write your controller's complete model number, serial number, and firmware version here so that you will have them available if you wish to contact a Lakewood Instruments technician.


Model Number:

Serial Number:


Firmware Version:

10.0 Drawings

REVISION HISTORY						
REV.	DATE	DESCRIPTION	BY	APP.	DATE	APP.
A	RELEASE	RELEASE	10/14	EJ	11/18/07	




INCORRECT




CORRECT

NOTE: TO ENSURE PROPER FUNCTION, SENSOR TIP MUST BE FULLY IMMERSIED WITHIN THE ACTIVE PROCESS STREAM. IF INSTALLED INCORRECTLY, AIR MAY ACCUMULATE AROUND THE SENSOR TIP, OR, LIMITED FLOW AROUND THE SENSOR MAY CAUSE INACCURATE READINGS.



INCORRECT






CORRECT



NOTES OR DIMENSIONS					
DATE:	REV:	BY:	APP:	INSTALLATION LAYOUT 540 & 543 COND. SENSORS	
				11DB74C-1a	
ORDER NO.	REV. NO.	DATE/REV.			REV. A
CUSTOMER					
CUSTOMER LOG.					
DO NOT SCALE					

pH/ORP SENSOR MOUNTING SUGGESTIONS

REVISION HISTORY						
REV	DATE	DESCRIPTION	BY	APP	DATE	APP
A		RELEASE	10/94	EV	5/18/97	




BYPASS FLOW CELL



SUBMERSION

NOTES ON REPRESENTATIONS				Lainwood INSTRUMENTS			
DATE	REV	BY	APP	DATE	REV	BY	APP
PROJECT NO. _____ DRAWING NO. _____ SHEET NO. _____				INSTALLATION LAYOUT 520, 521, 530 pH/ORP MOUNT SENSOR 1B40580_1a			
DO NOT SCALE				SCALE NONE			


REVISION HISTORY					
REV	DESCRIPTION	EDD	DWN	DATE	APVD
A	RELEASE	0491	NLM	4/88	
B	REVISED	1121	EV	6/25/87	



NOTICE ON REPRODUCTIONS THIS DRAWING IS THE PROPERTY OF LAKWOOD INSTRUMENTS. IT IS TO BE USED ONLY FOR THE PROJECT AND QUANTITY SPECIFIED. ANY REUSE OR REPRODUCTION WITHOUT THE WRITTEN PERMISSION OF LAKWOOD INSTRUMENTS IS STRICTLY PROHIBITED.					
MATERIAL: FINISH:		FINANCIAL: 03/15		TITLE: WIRING DIAGRAM SENSOR WIRING, INPUT WIRING M-2175Pe	
ORDER NO.		DWN NLM DATE 4/86		DWN NLM DATE 4/86	
CUSTOMER:		APVD DDR DATE 4/88		DWN NLM 1268870_2a	
CUSTOMER LOC.		APVD		REV B	
DO NOT SCALE		APVD		SCALE NONE	
		DATE		FILE TYPE DWG SHEET 1 OF 1	

FOR DATA REVIEW ONLY


REVISION HISTORY					
REV	DESCRIPTION	EGG	DWH	DATE	APVD
A	RELEASE	10061	PSG	2-27-07	



- NOTES (UNLESS OTHERWISE NOTED)
- ① PLACE A JUMPER WIRE FROM V+ TO I+.
 - ② PLACE A JUMPER WIRE FROM V- TO I-.

<p>NOTICE ON REPRODUCTIONS THIS DRAWING IS THE PROPERTY OF LAKWOOD INSTRUMENTS. IT IS TO BE USED ONLY FOR THE PROJECT AND THE CLIENTS IT SERVES. ALL RIGHTS ARE RESERVED. ANY REPRODUCTION OR TRANSMISSION OF THIS DRAWING WITHOUT THE WRITTEN PERMISSION OF LAKWOOD INSTRUMENTS IS STRICTLY PROHIBITED.</p>					
<p>UNITS: INCHES DECIMALS .005 ± .001 .001 ± .001 .0005 ± .0005</p>	<p>UNITS: MILLIMETERS DECIMALS .02 ± .001 .01 ± .001 .005 ± .001</p>	<p>TITLE: WIRING DIAGRAM 540 SENSOR WIRING, N-2175Pe</p>			
<p>ORDER NO. DWH P29</p>	<p>DATE: 2-27-07</p>	<p>SCALE: B</p>	<p>DATE: 2-27-07</p>	<p>DWG NO/TN: 1269870_1a</p>	<p>REV: A</p>
<p>CUSTOMER: [blank]</p>	<p>DATE: [blank]</p>	<p>SCALE: NONE</p>	<p>DATE: [blank]</p>	<p>FILE TYPE: DWG</p>	<p>SHEET 1 OF 1</p>
<p>CUSTOMER LOG: [blank]</p>	<p>DATE: [blank]</p>	<p>SCALE: NONE</p>	<p>DATE: [blank]</p>	<p>FILE TYPE: DWG</p>	<p>SHEET 1 OF 1</p>

REVISION HISTORY					
REV	DESCRIPTION	EDG	DWN	DATE	APVD
A	RELEASE	D491	NLM	4/98	DDR
B	REVISED	1121	EV	8/22/07	



NOTICE ON REPRODUCTIONS
 THIS DRAWING IS THE PROPERTY OF LAKWOOD INSTRUMENTS. IT IS TO BE USED ONLY FOR THE PROJECT AND QUANTITY SPECIFIED. ANY OTHER USE WITHOUT THE WRITTEN PERMISSION OF LAKWOOD INSTRUMENTS IS PROHIBITED.

MATERIAL	FRAG	DECIMALS	ANGLES
FINISH		.000 ± .005	
ORDER NO.	DWN NLM	DATE 4/98	
CUSTOMER	D491 JWC	DATE 4/98	
CUSTOMER LOC.	APVD DDR	DATE 4/98	
DO NOT SCALE	APVD	DATE	







TITLE		WIRING DIAGRAM	
SENSOR WIRING, INPUT WIRING M-2330P			
SIZE	DWG	DWG NO/REV	REV
B		1168332_1b	B
SCALE	NONE	FILE TYPE	DWG
		SHEET	1 OF 1

NOTES: UNLESS OTHERWISE SPECIFIED;

- 1 2450: CANNOT BE USED WITH CONTACTING HEAD METER.
- 2 2450: METER 1 IS PERMEATE, METER 2 IS CONCENTRATE.
- 3 CUSTOMER SUPPLIED, 10K RESISTOR (PULL-UP).
- 4 ONLY OPEN COLLECTOR OUTPUT WATER METERS MAY BE USED.

REVISION HISTORY						
REV	DATE	DESCRIPTION	BY	APP	DATE	APP
A		RELEASE	1121	EV	01/03/97	
B		RELEASE	0280	EV	01/03/97	
D		RELEASE	1267	EV	12/01/97	
D		RELEASE	1480	EV	11/23/97	MS
E		ADDED METER 2	1564	EV	01/18/98	MS
F		CHANGE HEAD, 6300 BOARD	1743	EV	01/18/98	




NOTICE TO SUBSTITUTIONS				Lakewood INSTRUMENTS	
DATE	REV	DESCRIPTION	BY	DATE	APP
		30 2 V			
		02 2 100			
		008 2 100			
ORDER NO.	REV	DATE	BY	DATE	APP
1109544-24		01/18/98	EV		
REVISION	DATE	BY	APP	DATE	APP
DO NOT SCALE	APPD	DATE	BY	DATE	APP



WIRING DIAGRAM
WATER METER INPUTS, M-2000 SERIES

1109544-24

REV F


REVISION		REVISION HISTORY			
DWG	PART	DESCRIPTION	ECO	DWN/DATE	APV/DATE
A	A	RELEASE	10042	PSG/ 5-3-06	LRS/ 7-28-06





NOTICE ON REPRODUCTIONS							
<small>THIS DRAWING, THE DESIGN, AND THE PATENTS IT COVERS ARE THE PROPERTY OF LAKEWOOD INSTRUMENTS INC. THEY ARE LOANED MERELY TO THE BORROWER UNDER AGREEMENT THAT THEY WILL NOT BE REPRODUCED, COPIED, LOANED, CHANGED, NOT USED EXCEPT IN THE MANNER SHOWN AND THE RIGHTS NOT PERMITTED BY WRITTEN CONSENT GIVEN BY THE LENDER TO THE BORROWER.</small>							
DIMENSIONING AND TOLERANCING PER ASME Y14.5M-1994							
MATERIAL	TOLERANCES UNLESS NOTED		TITLE		WIRING DIAGRAM, 2000 SERIES NEMA ENCLOSURE		
	DECIMALS X ±	FRACTIONS ±					
FINISH	DWN PSG	DATE 5-3-06	SIZE A		PN 1268647	REV A	
PROJECT:	CHKD RCL	DATE 7-28-06	SCALE NTS	SHEET 1	DWG NO 1268647-1a	REV A	
LIBRARY:	VERSION						

NOTES: UNLESS OTHERWISE SPECIFIED:
 ⚠ STANDARD FOUR CONDUCTOR TELEPHONE CABLE
 UP TO 50 FEET IN LENGTH MAY BE SUBSTITUTED.

REVISION HISTORY					
REV	DATE	DESCRIPTION	BY	CHKD	APPD
A		ISSUED	CHT	MLM	1/78
B		REVISED	ETD	MLM	8/78
C		REVISED	CHT	ML	12/81
D		REVISED	YHS	ML	11/94/97



PERSONAL COMPUTER WITH MODEM



DO NOT PLUG RJ21 DIRECTLY INTO TELEPHONE LINES

1	PCB	PCB, COM NODE	ASSEMBLED PCB, M-2000	4
1	6636	CABLE, RJ21, 25 FT.		3
1	6776C	ADAPTER	25 P MALE D DOWN TO RJ21 DTE	2
1	6774D	MODEM	HAYES COMPATIBLE	1

DATE SHIP

WORK IN PROGRESS

Labrador INSTRUMENTS

INSTALLATION LAYOUT
 COMNODE TO SSP DTE, SER 2000, REQD

REV 1109706-1d

REV D



4 1 3 2 1 1

NOTES: UNLESS OTHERWISE SPECIFIED;

- 1. STANDARD FOUR CONDUCTOR TELEPHONE CABLE UP TO 50 FEET IN LENGTH MAY BE SUBSTITUTED.

REVISION HISTORY						
REV	DATE	DESCRIPTION	EN	APP	DATE	APP
A	REL/MS	RELEASE	1367	DJ	10/28/97	
B	RSZL	RSZL	1367	DJ	10/28/97	
B	RSZL	RSZL	1485	DJ	11/14/97	MS

PERSONAL COMPUTER WITH MODEM



DO NOT PLUG RS22 DIRECTLY INTO TELEPHONE LINES


1	87309	ADAPTER, 8 PIN	MALE COAX TO 8/11 DTE	3
1	88336	CABLE, RJ21	25 FT	2
1	RS22	RS22 COM MODULE	ASSEMBLED PCB, M-2000	1

REVISED BY		DATE		DESCRIPTION	

		Labwood INSTRUMENTS	
TITLE INSTALLATION LAYOUT RS22 DIRECT CONNECT TO 8 PIN RS22		PART NO. U199700-000	


NOTES: UNLESS OTHERWISE SPECIFIED;
 1. LOADS MUST BE LESS THAN 600Ω

REVISION HISTORY						
REV	DATE	DESCRIPTION	BY	APP	DATE	APP
A		RELEASE	BTG	BT	8/88	
B		REVISED	CBT	BT	10/8/87	



INTERNAL POWER

OPTIONAL EXTERNAL 24 VDC SUPPLY




TITLE				Lakewood INSTRUMENTS	
WIRING DIAGRAM				POWER SUPPLY, 24VDC, 4 TO 20 mA	
11097D7-1b				REV	B
DO NOT SCALE				DATE	11/8/87

NOTES: UNLESS OTHERWISE SPECIFIED;

1. NIN OPTION PROVIDES +24 VDC TO ALL NODES. IF USING MORE THAN 3 NODES AN EXTERNAL +24 VDC POWER SUPPLY IN PARALLEL IS RECOMMENDED.

REVISION HISTORY						
REV	DATE	DESCRIPTION	BY	APP	DATE	APP
A		RELEASE	1040	EV	01/14/87	



OR

NOTES ON REPRESENTATIONS				Lakewood INSTRUMENTS	
FIGURE	NAME	DATE	BY	FILE	INSTALLATION DRAWING
PROJECT	NO.	REV	BY		NIN OPTION
ORDER NO.	REV	DATE	BY		1187805-1a
CONTAINER	REV	DATE	BY		
DESIGNER	REV	DATE	BY		
DO NOT SCALE	REV	DATE	BY		

For more information call toll free in the USA (800) 228-0839

Manufactured in the USA

Lakewood Instruments

7838 North Faulkner Road, Milwaukee, WI 53224 USA

Phone (800) 228-0839 • Fax (414) 355-3508

<http://www.lakewoodinstruments.com>